KEITHLEY

Model 197A
Autoranging Microvolt DMM

Instruction Manual



Model 197A
Autoranging Microvolt DMM

Instruction Manual



Contains Operating and Servicing Information

KEITHLEY

WARRANTY

Keithley Instruments, Inc. warrants this product to be free from defects in material and workmanship for a period of 1 year from date of shipment.

Keithley Instruments, Inc. warrants the following items for 90 days from the date of shipment: probes, cables, rechargeable batteries, diskettes, and documentation.

During the warranty period, we will, at our option, either repair or replace any product that proves to be defective.

To exercise this warranty, write or call your local Keithley representative, or contact Keithley headquarters in Cleveland, Ohio. You will be given prompt assistance and return instructions. Send the product, transportation prepaid, to the indicated service facility. Repairs will be made and the product returned, transportation prepaid. Repaired or replaced products are warranted for the balance of the original warranty period, or at least 90 days.

LIMITATION OF WARRANTY

This warranty does not apply to defects resulting from product modification without Keithley's express written consent, or misuse of any product or part. This warranty also does not apply to fuses, software, non-rechargeable batteries, damage from battery leakage, or problems arising from normal wear or failure to follow instructions.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE. THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES.

NEITHER KEITHLEY INSTRUMENTS, INC. NOR ANY OF ITS EMPLOYEES SHALL BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF ITS INSTRUMENTS AND SOFTWARE EVEN IF KEITHLEY INSTRUMENTS, INC., HAS BEEN ADVISED IN ADVANCE OF THE POSSIBILITY OF SUCH DAMAGES. SUCH EXCLUDED DAMAGES SHALL INCLUDE, BUT ARE NOT LIMITED TO: COSTS OF REMOVAL AND INSTALLATION, LOSSES SUSTAINED AS THE RESULT OF INJURY TO ANY PERSON, OR DAMAGE TO PROPERTY.

KEITHLEY

Test Instrumentation Group, Keithley Instruments, Inc. • 28775 Aurora Road • Cleveland, Ohio 44139 • (216) 248-0400 • Fax: (216) 248-6168

CHINA:	**Keithley Instruments, Inc.** • Holiday Inn Lido • Office Building 404C • Beijing, China, 100004 • 8610-436-2871/2860 • 8610-436-2871
FRANCE:	**Keithley Instruments SARL** • 3 Allée des Garays • B.P. 60 • 91122 Palaiseau Cédex • 01-60-11-51-55 • Fax: 01-60-11-77-26
GERMANY:	**Keithley Instruments GmbH** • Landsberger Str. 65 • 82110 Germering • 089-849307-0 • Fax: 089-84930759
GREAT BRITAIN:	**Keithley Instruments, Ltd.** • The Minster • 58 Portman Road • Reading, Berkshire RG30 1EA • 01734-575666 • Fax: 01734-596469
ITALY:	**Keithley Instruments SRL** • Viale S. Gimignano 38 • 20146 Milano • 02-48303008 • Fax: 02-48302274
JAPAN:	**Keithley Instruments Far East KK** • Sumiyoshi 24 Bldg., Room 201 • 2-24-2 Sumiyoshi-cho • Naka-ku, Yokohama 231 • 81-45-201-2246 • Fax: 81-45-201-2247
NETHERLANDS:	**Keithley Instruments BV** • Avelingen West 49 • 4202 MS Gorinchem • Postbus 559 • 4200 AN Gorinchem • 01830-35333 • Fax: 01830-30821
SWITZERLAND:	**Keithley Instruments SA** • Kriesbachstrasse 4 • 8600 Dübendorf • 01-821-9444 • Fax: 01-820-3081

Model 197A Autoranging Microvolt DMM Instruction Manual

© 1990, Keithley Instruments, Inc.
Test Instrumentation Group
All rights reserved.
Cleveland, Ohio, U.S.A.
Document Number: 197A-901-01 Rev. A

All Keithley product names are trademarks or registered trademarks of Keithley Instruments, Inc.

Other brand and product names are trademarks or registered trademarks of their respective holders.

SAFETY PRECAUTIONS

The following safety precautions should be observed before operating the Model 197A.

This instrument is intended for use by qualified personnel who recognize shock hazards and are familiar with the safety precautions required to avoid possible injury. Read over the manual carefully before operating this instrument.

Exercise extreme caution when a shock hazard is present at the instrument's input. The American National Standards Institute (ANSI) states that a shock hazard exists when voltage levels greater than 30V rms or 42.4V peak are present. **A good safety practice is to expect that a hazardous voltage is present in any unknown circuit before measuring.**

Inspect the test leads for possible wear, cracks or breaks before each use. If any defects are found, replace the test leads.

For optimum safety do not touch the test leads or the instrument while power is applied to the circuit under test. Turn the power off and discharge all capacitors, before connecting or disconnecting the instrument.

Do not touch any object which could provide a current path to the common side of the circuit under test or power line (earth) ground. Always make measurements with dry hands while standing on a dry, insulated surface, capable of withstanding the voltage being measured.

Exercise extreme safety when testing high energy power circuits (AC line or mains, etc). Refer to High Energy Circuit Safety Precautions found in paragraph 2.2.

Do not exceed the instrument's maximum allowable input as defined in the specifications and operation section.

Instrumentation and accessories should not be connected to humans.

Model 197A Autoranging DMM

DC VOLTS

RANGE	RESOLUTION	INPUT RESISTANCE	ACCURACY** ±(%rdg + counts) 24 Hr.,* 22°–24°C	1 Year, 18°–28°C
200 mV	1 µV	>1 GΩ	0.007 + 2	0.016 + 3
2 V	10 µV	>1 GΩ	0.005 + 2	0.011 + 2
20 V	100 µV	11 MΩ	0.006 + 2	0.015 + 3
200 V	1 mV	10 MΩ	0.006 + 2	0.015 + 2
1000 V	10 mV	10 MΩ	0.007 + 2	0.015 + 2

*Relative to calibration accuracy. **When properly zeroed.

NMRR: >60dB at 50Hz, 60Hz ±0.1%.

MAXIMUM ALLOWABLE INPUT: 1000V DC or peak AC (<10 seconds per minute on 200mV and 2V ranges; 300V rms continuous).

SETTLING TIME: 1 second to within 3 counts of final reading on range.

dB MODE (ref: 600Ω): Accuracy: ±(0.02dB+1 count) above –78dBm.

RESOLUTION: 0.01dB above 0.5% of range.

dB REFERENCE IMPEDANCE: 50, 75, 93, 135, 300, or 600 ohms (default), front panel selectable.

TRMS AC VOLTS

RANGE	ACCURACY (1 Year)* 18°–28°C ±(%rdg + counts) 20Hz–50Hz	50Hz–10kHz	10kHz–20kHz	20kHz–50kHz	50kHz–100kHz
200 mV	1.00 + 100	0.35 + 100	0.6 + 200	1.5 + 250	5 + 400
2V–200V	1.00 + 100	0.35 + 100	0.6 + 200	1.5 + 250	3 + 400
750 V	1.25 + 100	0.5 + 100	1.0 + 200	1.8 + 250	3 + 400

*Above 1800 counts. **Above 18000 counts.

MAXIMUM ALLOWABLE INPUT: 750V rms, 1000V peak (<10 seconds per minute on 200mV and 2V ranges; 300V rms continuous). 10^7 V•Hz maximum.

3dB BANDWIDTH: 300kHz typical.

INPUT IMPEDANCE: 1MΩ paralleled by <75pF on 200V and 750V ranges; 1.1MΩ on 200mV, 2V, and 20V ranges. Capacitively coupled.

SETTLING TIME: 1 second to within 0.1% of final reading on range.

dB MODE: (ref: 600Ω):

RANGE	INPUT	ACCURACY (±dBm) 20Hz–10kHz	10kHz–20kHz	20kHz–50kHz	50kHz–100kHz
2V–750V	200 mV to 750 V (–12 to 59.8dBm)	0.18	0.18	0.28	0.50
200 mV	20 mV to 200 mV (–32 to –12dBm)	0.18	0.18	0.28	0.65
	2 mV to 20 mV (–52 to –32dBm)	0.85	1.10	2.00	—
	1 mV to 2 mV (–58 to –52dBm)	2.00	3.00	—	—

RESOLUTION: 0.01dBm above 0.5% of range.

dB REFERENCE IMPEDANCE: 50, 75, 93, 135, 300, or 600 ohms (default), front panel selectable.

DC AMPS

RANGE	RESOLUTION	MAXIMUM VOLTAGE BURDEN	ACCURACY (1 Year) 18°–28°C ±(%rdg + counts)
200 µA	1 nA	0.3 V	0.1 + 15
2 mA	10 nA	0.3 V	0.1 + 15
20 mA	100 nA	0.3 V	0.1 + 15
200 mA	1 µA	0.3 V	0.2 + 15
2000 mA	10 µA	0.8 V	0.2 + 15
10 A	100 µA	0.3 V	0.5 + 15*

*Above 5A derate 0.15% rdg per amp for self-heating.

OVERLOAD PROTECTION: mA Input: 2A fuse (250V), externally accessible. 10A Input: 20A for 15s, unfused.

SETTLING TIME: 1 second to within 3 counts of final reading.

TRMS AC AMPS

RANGE	MAXIMUM VOLTAGE BURDEN	ACCURACY (1 Year)* 18°–28°C ±(%rdg+counts) 20Hz–50Hz	50Hz–10kHz	10kHz–30kHz
200µA–20mA	0.3 V	1.0 + 100	0.8 + 100	2 + 250
200 mA	0.3 V	1.0 + 100	0.8 + 100	—
2000 mA	0.8 V	1.0 + 100	0.8 + 100	—
10 A	0.3 V	1.5 + 100	1.0 + 100**	—

*Above 1800 counts. **1kHz max. Above 5A derate 0.15% rdg/amp for self-heating.

SETTLING TIME: 1 second to within 0.1% of final reading.

OHMS

RANGE	RESOLUTION	OUTPUT NOMINAL I-SHORT	MAX. V ACROSS UNKNOWN	ACCURACY ±(%rdg+counts) 24 Hr., 22°–24°C	1 Year, 18°–28°C
200 Ω	1 mΩ	2 mA	0.5 V	0.01 + 2*	0.018 + 3*
2 kΩ	10 mΩ	2 mA	4.0 V	0.01 + 2	0.018 + 2
20 kΩ	100 mΩ	400 µA	4.0 V	0.014 + 2	0.026 + 2
200 kΩ	1 Ω	40 µA	4.0 V	0.014 + 2	0.026 + 2
2 MΩ **	10 Ω	4 µA	4.0 V	0.02 + 2	0.035 + 2
20 MΩ **	100 Ω	400 nA	4.0 V	0.10 + 2	0.12 + 2
200 MΩ **	10 kΩ	400 nA	5.0 V	2.00 + 1	2.00 + 1

*When properly zeroed. **Appropriate range selected automatically in MΩ.

CONFIGURATION: Automatic 2 or 4-terminal.

MAXIMUM ALLOWABLE INPUT: 450V DC or peak AC 10 seconds per minute. 350V rms continuous.

OPEN CIRCUIT VOLTAGE: +5V.

DIODE TEST: Display reads junction voltage up to 2.2V. Test Current: 1.6mA nominal.

SETTLING TIME: 2 seconds to within 3 counts of final reading on range.

ANALOG/IEEE OUTPUT (Model 1972A Option)

ANALOG OUTPUT:

Accuracy: ±(0.25% of displayed reading + 2mV).

Response Time: Follows display conversion rate.

Level: 1V=100,000 counts on ×1 gain. 1V=100 counts on ×1000 gain. Maximum output voltage = 4V.

Output Resistance: 1000Ω.

Isolation: 500V peak, Input LO to Output LO. 30V peak, output LO to earth ground.

IEEE OUTPUT: See IEEE BUS IMPLEMENTATION.

IEEE BUS IMPLEMENTATION

(1972A Analog/IEEE & 1973A IEEE Options)

MULTILINE COMMANDS: DCL, SDC, GET, GTL, UNT, UNL, SPE, SPD.

UNILINE COMMANDS: IFC, REN, EOI, SRQ, ATN.

INTERFACE FUNCTIONS: SH1, AH1, T5, TE0, L4, LE0, SR1, RL0, PP0, DC1, DT1, C0, E1.

PROGRAMMABLE PARAMETERS: Range, REL, dB, EOI, Trigger, Calibration, SRQ, Status, Output Format, Terminator, Data Logger Retrieval.

GENERAL

DISPLAY: ±220,000-count LCD with backlight (switch selectable), 0.45 in. height; polarity, function, range, and status indication.

RANGING: Auto or manual on DC volts, AC volts, and ohms; manual on AC amps and DC amps.

AUTORANGING TIME: 300ms per range average.

RELATIVE: Pushbutton allows zeroing of on range readings. Allows readings to be made with respect to baseline value. Front panel annunciator indicates REL mode.

DATA LOGGER and MIN/MAX: 100 reading storage capacity; records data at one of six selectable rates from 3 readings/second to 1 reading/hour or by manual triggering. Also detects and stores maximum and minimum readings continuously while in data logger mode.

CONVERSION RATE: 3 readings/second.

OVERRANGE INDICATION: "OL" displayed.

CREST FACTOR (ratio of peak value to rms value), AC FUNCTIONS: 3.

MAXIMUM COMMON MODE VOLTAGE: 500V peak.

COMMON MODE REJECTION RATIO (1kΩ unbalance): >120dB at DC, 50Hz, 60Hz ±0.1%. >60dB in AC volts.

TEMPERATURE COEFFICIENT (0°–18°C & 28°–50°C): ±(0.1 × applicable one year accuracy specification)/°C.

ENVIRONMENT: Operating: 0°–50°C; <80% relative humidity up to 35°C; linearly derate 3% RH/°C, 35°–50°C. **Storage:** –40° to +70°C.

WARM-UP: 1 hour to rated accuracy.

POWER: 105–125V or 210–250V (external switch selected), 90–110V available; 50–60Hz, 12VA. Removable power cord. Optional 5-7 hour battery pack, Model 1978.

DIMENSIONS, WEIGHT: 89mm high ×235mm wide × 275mm deep (3½ in. × 9¼ in. × 10¾ in.). Net weight 1.8kg (3 lbs., 14 oz.).

ACCESSORIES SUPPLIED: Model 1751 Safety Test Leads, instruction manual.

Specifications subject to change without notice.

Digitized by the Internet Archive
in 2024

https://archive.org/details/manualsplus_01597

Table of Contents

SECTION 1 — General Information

1.1 INTRODUCTION 1-1
1.2 FEATURES 1-1
1.3 WARRANTY INFORMATION 1-2
1.4 MANUAL ADDENDA 1-2
1.5 SAFETY SYMBOLS AND TERMS 1-2
1.6 SPECIFICATIONS 1-2
1.7 UNPACKING AND INSPECTION 1-2
1.8 USING THE MODEL 197A MANUAL 1-2
1.9 INITIAL OPERATION 1-3
1.10 ACCESSORIES 1-3

SECTION 2 — Bench Operation

2.1 INTRODUCTION 2-1
2.2 HIGH ENERGY CIRCUIT SAFETY PRECAUTIONS 2-1
2.3 PREPARATION FOR USE 2-2
2.3.1 Line Power 2-2
2.3.2 Battery Pack Power 2-2
2.3.3 Battery Charging 2-2
2.4 FRONT AND REAR PANEL FAMILIARIZATION 2-2
2.4.1 Display 2-2
2.4.2 Front Panel Controls 2-4
2.4.3 Input Terminals 2-4
2.4.4 Current Fuse Replacement 2-4
2.4.5 Rear Panel Switches 2-5
2.5 ERROR MESSAGES 2-5
2.6 OPERATING CONDITIONS 2-5
2.6.1 Environmental Conditions 2-5
2.6.2 Maximum Allowable inputs 2-5
2.6.3 Warm Up 2-6
2.7 BASIC BENCH MEASUREMENTS 2-6
2.7.1 Power Up 2-6
2.7.2 Relative Mode 2-6
2.7.3 DC Voltage Measurement 2-7
2.7.4 TRMS AC Voltage Measurements 2-8
2.7.5 Microvolt Measurement Considerations 2-8
2.7.6 Resistance Measurements 2-9
2.7.7 Current Measurements (DC or TRMS AC) 2-11
2.7.8 AC Plus DC Measurements 2-12
2.7.9 dB Measurements 2-13
2.7.10 dB Measurement Considerations and Applications 2-15
2.7.11 MIN/MAX and 100 Point Data Logger Operation 2-16

2.7.12 Diode Test 2-16
2.8 TRMS CONSIDERATIONS 2-17
2.8.1 AC Voltage Offset 2-17
2.8.2 TRMS Measurement Comparison 2-17
2.8.3 Crest Factor 2-17
2.8.4 Extended Frequency Response 2-17

SECTION 3 — Performance Verification

3.1 INTRODUCTION 3-1
3.2 ENVIRONMENTAL CONDITIONS 3-1
3.3 RECOMMENDED TEST EQUIPMENT 3-1
3.4 INITIAL CONDITIONS 3-1
3.5 VERIFICATION PROCEDURE 3-2
3.5.1 DC Voltage Accuracy Check 3-2
3.5.2 AC Voltage Accuracy Check 3-3
3.5.3 Resistance Accuracy Check 3-4
3.5.4 DC Current Accuracy Check 3-6
3.5.5 AC Current Accuracy Check 3-7

SECTION 4 — Theory of Operation

4.1 INTRODUCTION 4-1
4.2 OVERALL FUNCTIONAL DESCRIPTION 4-1
4.3 ANALOG CIRCUITRY 4-1
4.3.1 Multiplexer 4-1
4.3.2 Input Buffer Amplifier 4-1
4.3.3 2V Reference Source 4-3
4.3.4 Input Signal Conditioning 4-3
4.3.5 A/D Converter 4-5
4.3.6 AC Converter 4-6
4.4 DIGITAL CIRCUITRY 4-6
4.4.1 Microcomputer 4-6
4.4.2 Address Decoding 4-7
4.4.3 PIA 4-7
4.4.4 Display Board 4-7
4.5 DIGITAL CALIBRATION 4-7
4.6 POWER SUPPLY 4-7
4.7 MODEL 1978 BATTERY OPTION 4-7
4.8 ELECTROLUMINESCENT DISPLAY BACKLIGHT 4-7

SECTION 5 — Maintenance

5.1 INTRODUCTION 5-1
5.2 DISASSEMBLY INSTRUCTIONS 5-1
5.3 BATTERY PACK (Model 1978) INSTALLATION 5-3
5.4 LINE VOLTAGE SELECTION 5-4
5.5 FUSE REPLACEMENT 5-5
5.5.1 Line Fuse Replacement 5-5

5.5.2 Current Fuse Replacement 5-5
5.6 FRONT PANEL CALIBRATION 5-5
5.6.1 Recommended Calibration Equipment 5-6
5.6.2 Environmental Conditions 5-6
5.6.3 Calibration Switch 5-6
5.6.4 DC Voltage Calibration 5-6
5.6.5 AC Voltage Calibration 5-7
5.6.6 Frequency Compensation 5-7
5.6.7 Resistance Calibration 5-9
5.6.8 Calibration Storage 5-10
5.7 TROUBLESHOOTING 5-10
5.7.1 Power Up Sequence 5-10
5.7.2 Self Diagnostic Program 5-11
5.7.3 Power Supply and Battery Pack (Model 1978) Checks 5-12
5.7.4 A/D Converter and Display 5-12
5.7.5 Signal Conditioning 5-12
5.8 SPECIAL HANDLING OF STATIC-SENSITIVE DEVICES 5-12

SECTION 6 — Replaceable Parts

6.1 INTRODUCTION 6-1
6.2 REPLACEABLE PARTS 6-1
6.3 ORDERING INFORMATION 6-1
6.4 FACTORY SERVICE 6-1
6.5 SCHEMATIC DIAGRAMS AND COMPONENT LOCATION DRAWINGS 6-1

List of Illustrations

SECTION 2 — Bench Operation

Figure 2-1 Model 197A Front Panel 2-3
Figure 2-2 Model 197A Rear Panel 2-3
Figure 2-3 DC Voltage Measurements 2-7
Figure 2-4 TRMS AC Voltage Measurements 2-8
Figure 2-5 Four Terminal Zeroing 2-10
Figure 2-6 Two Terminal Resistance Measurement 2-11
Figure 2-7 Four Terminal Resistance Measurement 2-11
Figure 2-8 Current Measurement Between 2000mA and 20A 2-12
Figure 2-9 Current Measurements up to 2000mA 2-12
Figure 2-10 Typical ACV Frequency Response 2-18

SECTION 3 — Performance Verification

Figure 3-1 Connections for DCV Verification 3-2
Figure 3-2 Connections for ACV Verification 3-4
Figure 3-3 Connections for 200Ω, 2kΩ and 20kΩ Range Verification (4-terminal) 3-5
Figure 3-4 Connections for 200kΩ through MΩ Ranges Verification (2-terminal) 3-5
Figure 3-5 Connections for DC Current Verification (200mA to 2000mA) 3-6
Figure 3-6 Connections for DC Current Verification (2000mA to 20A) 3-7
Figure 3-7 Connections for AC Current Verification (200mA to 2000mA) 3-8
Figure 3-8 Connections for AC Current Verification (2000mA to 10A) 3-8

SECTION 4 — Theory of Operation

Figure 4-1 Simplified Block Diagram 4-2
Figure 4-2 JFET Multiplexer 4-3
Figure 4-3 Simplified Schematic of the Input Buffer Amplifier 4-3
Figure 4-4 Input Configuration During 2- and 4-Terminal Resistance Measurements 4-4
Figure 4-5 Resistance Measurement Simplified Circuit 4-5
Figure 4-6 A/D Converter 4-6

SECTION 5 — Maintenance

Figure 5-1 Model 197A Miscellaneous Parts 5-2
Figure 5-2 Display Assembly Exploded View 5-4
Figure 5-3 DC Voltage Calibration Configuration 5-7
Figure 5-4 AC Voltage Calibration Configuration 5-8
Figure 5-5 200, 2k and 20k Four Wire Resistance Calibration 5-9
Figure 5-6 200k, 2M and 20M Two Wire Resistance Calibration 5-10
Figure 5-7 Segment Identification 5-11

List of Tables

SECTION 2 — Bench Operation

Table 2-1 Error Messages 2-5
Table 2-2 Model 197A Maximum Allowable Inputs 2-6
Table 2-3 Resistance Ranges 2-10
Table 2-4 dB Specifications for DC Volts (600Ω Ref) 2-13
Table 2-5 dB Specifications for AC Volts (600Ω Ref) 2-13
Table 2-6 Selectable Reference Impedances 2-13
Table 2-7 Levels for Other Reference Impedances 2-14
Table 2-8 Comparison of Average and TRMS Meter Readings 2-19

SECTION 3 — Performance Verification

Table 3-1 Equipment Specifications 3-2
Table 3-2 Limits for DC Voltage Verification 3-3
Table 3-3 Limits for AC Voltage Verification 3-3
Table 3-4 Limits for Resistance Verification 3-4
Table 3-5 Limits for DC Current Verification 3-7
Table 3-6 Limits for AC Current Verification 3-9

SECTION 5 — Maintenance

Table 5-1 Input Terminal Identification 5-3
Table 5-2 Recommended Calibration Equipment 5-6
Table 5-3 DC Voltage Calibration 5-7
Table 5-4 AC Voltage Calibration 5-9
Table 5-5 Resistance Calibration 5-9
Table 5-6 Recommended Troubleshooting Equipment 5-10
Table 5-7 Model 197A Troubleshooting Mode 5-13
Table 5-8 Power Supply and Battery Pack (Model 1978) Checks 5-15
Table 5-9 Display Board Checks 5-16
Table 5-10 A/D Converter/Microcomputer Checks 5-16
Table 5-11 Model 197A Static Sensitive Devices 5-17

SECTION 1
General Information

1.1 INTRODUCTION

The Model 197A is a six function, 5-1/2 digit resolution autoranging digital multimeter with a ±220,000 count LCD (Liquid Crystal Display). This A/D range is greater than the normal ±199,999 count A/D used in many 5-1/2 digit DMMs. The 5-1/2 digit resolution allows the Model 197A to measure DC voltage for 1µV/count to 1000V. AC voltage and current measurements are standard in the Model 197A. TRMS ACV capability ranges from 1µV/count to 750V. The Model 197A measures resistance from 1mΩ to 220MΩ on seven resistance ranges. The Model 197A has six current ranges that measure current from 1nA (10^{-9}A) to 10A.

The dB function makes it possible to compress a large range of readings into a much smaller scope. Model 197A dBm measurements can be referenced to 50, 75, 93, 135, 300 or 600Ω (default), but can be modified with the use of the relative (REL) feature.

The Model 197A has two IEEE-488 interface options: The Model 1972A and the Model 1973A. These optional interfaces enhance the capabilities of the Model 197A by allowing programmed control over the IEEE-488 bus. The Model 1972A also includes an analog output. The bus commands are the same for each interface and respond to IEEE-488 protocol.

1.2 FEATURES

The Model 197A includes the following features:

1. Six Measurement Functions — DCV, ACV, DCA, ACA, OHMS and dB all built in.
2. (REL) Relative Mode — The relative mode allows offsets to be nulled out (e.g. test lead resistance for low resistance measurements) and selects a variety of reference impedances for dB measurements.
3. Digital Calibration — A non-volatile RAM stores calibration constants and can be performed from the front panel or over the IEEE-488 bus.
4. Data Logger — A data storage buffer is included to allow up to 100 readings and minimum/maximum readings be internally stored at a user selectable rate. The buffer may be read and controlled from the front panel or over the IEEE-488 bus. In the talk-only mode, the output rate can also be programmed.
5. Autoranging — The Model 197A includes a fast autoranging feature for easier measurements.
6. 5-1/2 Digit Resolution — The Model 197A has a ±220,000 count A/D that surpasses the more common ±199,999 count A/D.
7. Four Terminal Ohms — These terminals are used to eliminate the voltage from across the current carrying leads.
8. Sensitivity — The Model 197A has 1µV, 1mΩ and 1nA sensitivity. The 1µV of sensitivity allows minute levels of offset, temperature etc. A 1nA sensitivity allows low current measurements without special equipment. Measure leakage, bias and offset cur-

rent. A 1mΩ sensitivity allows easy low resistance measurements.

9. Electroluminescent Display Backlight — A switch selectable electroluminescent display backlight used to enhance the liquid crystal display under low light or dark conditions.
10. dB Reference Impedances — Selectable dB reference impedances of 50Ω, 75Ω, 93Ω, 135Ω, 300Ω and 600Ω (default).

1.3 WARRANTY INFORMATION

Warranty information may be found on the inside front cover of this manual. Should it become necessary to exercise the warranty, contact your Keithley representative or the factory to determine the proper course of action. Keithley Instruments maintains service facilities in the United States, United Kingdom and throughout Europe. Information concerning the application, operation or service of your instrument may be directed to the applications engineer at any of these locations. Check the inside front cover for addresses.

1.4 MANUAL ADDENDA

Information concerning improvements or changes to this instrument which occur after the printing of this manual will be found on an addendum sheet included with this manual. Be sure to review these changes before attempting to operate or service the instrument.

1.5 SAFETY SYMBOLS AND TERMS

The following safety symbols and terms are used in this manual or found on the Model 197A.

The symbol on the instrument denotes the user should refer to the operating instructions in this manual.

The symbol on the instrument denotes that a potential of 1000V or more may be present on the terminal(s). Standard safety practices should be observed when such dangerous levels are encountered.

The **WARNING** heading used in this manual explains dangers that could result in personal injury or death.

The **CAUTION** heading used in this manual explains hazards that could damage the instrument.

1.6 SPECIFICATIONS

Detailed Model 197A specifications may be found preceding the table of contents of this manual.

1.7 UNPACKING AND INSPECTION

The Model 197A Autoranging Microvolt DMM was carefully inspected, both electrically and mechanically before shipment. Upon receiving the instrument, carefully unpack all items from the shipping carton and check for any obvious signs of physical damage that may have occurred during transit. Report any damage to the shipping agent. Retain and use the original packing material in case reshipment is necessary. The following items are shipped with every Model 197A order:

- Model 197A Autoranging DMM
- Model 197A Instruction Manual
- Model 1751 Safety Shrouded Test Leads
- Additional accessories as ordered.

If an additional instruction manual is required, order the manual package (Keithley Part Number 197A-901-00). The manual package includes an instruction manual and any applicable addenda.

1.8 USING THE MODEL 197A MANUAL

This manual contains information necessary for operating and servicing the Model 197A Autoranging Microvolt DMM and the 1978 Rechargeable Battery Pack. This section of the manual contains general information and an initial operation procedure. The rest of the manual is organized as follows:

- Section 2 contains detailed bench operation information for the Model 197A.
- Section 3 contains the information needed to verify the accuracy of the Model 197A. Performance verification can be done upon receipt of the unit or whenever the basic accuracy of the instrument is in question.
- Information concerning theory of operation, maintenance and servicing is contained in Sections 4 through 6.

NOTE
The Models 1973A and 1972A IEEE-488 interfaces come supplied with their own instruction manual.

1.9 INITIAL OPERATION

Perform the following steps in sequence to acquaint yourself with the basic operation of the Model 197A.

- Verify that the instrument was not damaged in transit, (see paragraph 1.7).
- Carefully read over all safety information (see Section 2 Basic Operation).
- Refer to paragraph 2.3 (Line Power) and set the line voltage switch. Connect the female end of the power cord to the AC recepticle on the rear of the Model 197A. Plug the other end of the line cord into a properly grounded receptacle. If the Model 1978 is installed, the charging circuit is activated.
- Acquaint yourself with the front panel controls as follows:
  1. Turn on the instrument using the ON/OFF button. All of the zeroes are briefly displayed.
  2. Connect the supplied test leads to the HI and LO input terminals. Connect the red test lead to the HI terminal and the black test lead to the LO terminal. Short the test leads together.
  3. Select AC volts and autoranging by pressing in the AC/DC, V and AUTO buttons. The AC, AUTO and mV annunciators are displayed. Pressing in any of the other range buttons activates manual ranging. This is indicated by the absence of the AUTO annunciator.
  4. Select DC volts by releasing (out position) the AC/DC button. V is still selected. The AC annunciator turns off.
  5. Select the autoranging OHMS by pressing in the AUTO, and Ω buttons. DC must still be selected. The Ω (omega) symbol is displayed. Press the AC/DC button in (means select AC) and note the "Err" message is displayed. This indicates an invalid mode.
  6. Select AC or DC current by setting the AC/DC button accordingly and pressing in the A button. The annunciator that reflects the selected mode in displayed. Note that current will not autorange. The 10A and LO terminals must be used on the 10A range.
  7. Select dB by selecting AC or DC volts and pressing the dB button. The dB annunciator will turn on and the default reference impedance (600Ω) will be displayed momentarily. Pressing dB a second time disables the dB measurement mode. To select an alternate dB reference impedance, enable dB as previously described, but hold in the dB button to scroll through the alternate impedance selections. Release the dB button when the desired dB reference impedance is displayed. When finished, again press dB to exit the dB mode.
  8. The REL (relative) feature can be used with any measurement function: Volts, Amps, Ohms or dB. For example, select the ohms function and autorange. The display reads approximately 000.140Ω, which is the test lead resistance. Press the REL button. The REL annunciator is turned on and the display reads 000.000Ω. The relative level of 000.14Ω will be subtracted from all subsequent measurements. Press the REL button a second time to cancel the REL level.
  9. To activate the 100 point DATA LOGGER with minimum/maximum, press and hold in the STO/CLR button. When the reading rate r=0 is displayed release the STO/CLR button. The STO annunciator turns on. Press the RCL button and the last data point is briefly displayed followed by the reading (data). Other data points can be displayed by holding in the RCL button. Turn off the DATA LOGGER by pressing the STO/CLR button again.
  10. Turn on the display backlight by pressing in the rear panel Display Backlight pushbutton switch. Turn off the backlight by again pressing the pushbutton switch.

1.10 ACCESSORIES

The following accessories can be used with the Model 197A.

MODEL 1010 SINGLE RACK MOUNTING KIT — Used to mount one Model 197A in a standard 5-1/2" x 19" rack.

MODEL 1017 DUAL RACK MOUNTING KIT — Used to mount two Model 197As in a standard 5-1/4" x 19" rack.

MODEL 1301 TEMPERATURE PROBE — A rugged low cost temperature probe designed to allow precision temperature measurements from –55 to 150°C.

MODEL 1600A HIGH VOLTAGE PROBE — Extends DMM measurements to 40kV.

MODEL 1641 KELVIN TEST LEAD SET — Special clip leads allow 4-terminal measurements to be made while making only two connections.

MODEL 1651 50-AMPERE CURRENT SHUNT — The external 0.001Ω ±1% 4-terminal shunt, permits current measurements from 0 to 50A AC or DC.

MODEL 1681 CLIP ON TEST LEAD SET — Contains two leads, 1.2m (48") long terminated with banana plugs and spring action clip probes.

MODEL 1682 RF PROBE — Permits voltage measurements from 10kHz to 250MHz. AC to DC transfer accuracy is ±1dB from 100kHz to 250MHz at 1V, peak responding, calibrated in RMS of a sine wave.

MODEL 1684 HARD SHELL CARRYING CASE — Hard vinyl case, 100mm x 300mm x 350mm (4" x 13" x 14") has a fitted foam insert with room for the Model 197A, an instruction manual and small accessories.

MODEL 1685 CLAMP ON AC PROBE — Measure AC current by clamping on to a single conductor. Interruption of the circuit is unnecessary. The Model 1685 detects currents by sensing the changing magnetic produced by the current flow.

MODLE 1751 SAFETY TEST LEADS — This test lead set is supplied with every Model 197A. Finger guards and shrouded banana plugs help minimize the chance of making contact with live circuitry.

MODEL 1754 UNIVERSAL TEST LEAD KIT — A 12 piece test lead kit, with interchangeable plug-in accessories. Included in the kit is one set of test leads (1-red, 1-black), two spade lugs, two standard banana plugs, two phone tips (.06 DIA.) two hooks and miniature alligator clips (with boots).

MODEL 1972A ANALOG OUTPUT IEEE-488 INTERFACE — The Model 1972A is an optional IEEE-488 interface that includes all of the logic necessary to interface the Model 197A to the IEEE-488 bus. The Model 1972A is similar to the Model 1973A however, it contains an analog output. The analog output is a scaled output that follows the display of the Model 197A. The Model 1972A is field installable.

MODEL 1973A IEEE-488 INTERFACE — The Model 1973A is an optional IEEE-488 interface for the Model 197A. This interface adds extra versatility to the Model 197A by allowing the transmission of data and commands over the IEEE-488 bus. The interface provides all the logic necessary to interface the Model 197A to the bus using standard IEEE-488-1978 protocol. The Model 1973A is field installable.

MODEL 1978 RECHARGEABLE BATTERY PACK — The rechargeable battery pack allows off line or in the field operation of the Model 197A. The pack provides typically five hours operation from full charge. The battery pack contains its own charging circuit and can be recharged within 10 hours. The battery pack is field installable.

MODEL 7008 IEEE-488 DIGITAL CABLE — Useful for connecting the 1973 to the IEEE-488 bus. The Model 7008-3 is 0.9m (3 ft.) in length and has a standard IEEE-488 connector at each end. The Model 7008-6 is 1.8m (6 ft.) in length and has a standard IEEE-488 connector at each end.

SECTION 2
Bench Operation

2.1 INTRODUCTION

This section contains the information needed to prepare and operate the Model 197A as a bench DMM. Bench operation consists of using the Model 197A to perform basic voltage, current, resistance and dB measurements. Also, the operation of the data logger is covered. The capabilities of the Model 197A can be enhanced with the addition of the Model 1973A or Model 1972A IEEE-488 interface. IEEE operation is covered in the Model 1973/1972 Instruction Manual. The optional battery pack (Model 1978) is also covered in this section.

2.2 HIGH ENERGY CIRCUIT SAFETY PRECAUTIONS

To optimize safety when measuring voltage in high energy distribution circuits, read and use the directions in the following warning.

WARNING

Dangerous arcs of an explosive nature in a high energy circuit can cause severe personal injury or death. If the meter is connected to a high energy circuit when set to a current range, low resistance range or any other low impedance range, the circuit is virtually shorted. Dangerous arcing can result even when the meter is set to a voltage range if the minimum voltage spacing is reduced.

When making measurements in high energy circuits use test leads that meet the following requirements:

- Test leads should be fully insulated.
- Only use test leads that can be connected to the circuit (e.g. alligator clips, spade lugs, etc.) for hands-off measurements.
- Do not use test leads that decrease voltage spacing. This diminishes arc protection and creates a hazardous condition.

Use the following sequence when testing power circuits:

1. De-energize the circuit using the regular installed connect-disconnect device such as the circuit breaker, main switch, etc.
2. Attach the test leads to the circuit under test. Use appropriate safety rated test leads for this application.
3. Set the DMM to the proper function and range.
4. Energize the circuit using the installed connect-disconnect device and make measurements without disconnecting the DMM.
5. De-energize the circuit using the installed connect-disconnect device.
6. Disconnect the test leads from the circuit under test.

CAUTION

The maximum common-mode input voltage (the voltage between input LO and chassis ground) is 500V peak. Exceeding this value may damage the instrument.

2.3 PREPARATION FOR USE

2.3.1 Line Power

The Model 197A has a three-wire line cord which mates with third-wire grounded receptacles. Connect the instrument to AC line power as follows:

1. Set the LINE VOLTAGE switch on the back of the instrument to correspond to line voltage available. Ranges are 105V-125V or 210V-250V 50/60Hz AC.

CAUTION

Be sure that the power line voltage agrees with the indicated range on the panel of the instrument. Failure to observe this precaution may result in instrument damage.

2. Connect the female end of the power cord to the AC receptacle on the rear panel of the Model 197A. Plug in the other end of the power cord into a properly grounded receptacle.

WARNING

The Model 197A is equipped with a 3-wire power cord that contains a separate ground wire and is designed to be used with grounded outlets. Failure to use a grounded outlet may result in personal injury or death because of electric shock.

NOTE

Although the Model 197A is specified at 50 and 60Hz the instrument may be operated at 400Hz and 440Hz.

2.3.2 Battery Pack Power

The Model 197A may be operated from rechargeable sealed nickel-cadmium batteries contained in the optional Model 1978 Rechargeable Battery Pack. The battery pack will operate the Model 197A for typically five hours (NOTE: The Model 197A uses the most power with the backlight on, and the amps function and on the 200Ω, 2kΩ or 750VAC ranges). The BAT annunciator turns on when the charge is insufficient to maintain accurate readings. Refer to paragraph 5.3 for installation procedures.

2.3.3 Battery Charging

After the Model 1978 is installed in the Model 197A it can be charged and recharged as follows:

1. Connect the instrument to line power as described in paragraph 2.3.1.
2. With the power switch off, the battery charge circuitry is automatically energized to charge the battery at the maximum rate. When the battery pack is first installed, or if it is completely discharged, allow it to charge for a minimum of 10 hours.

NOTE

For maximum battery efficiency only charge the battery pack after it has become completely discharged (BAT annunciator on). Do not make measurements with BAT annunciator on as the readings may be erroneous.

If the battery pack is not maintaining a charge (BAT off) for five hours after a full 10 hour charge cycle, do the following.

A. Disconnect the Model 197A from line power.
B. Turn on the Model 197A and leave it on to completely discharge the battery pack.
C. Connect the Model 197A to line power and charge the battery pack for 10 hours with power off.
D. Repeat steps A through C three more times. The battery pack should again be good for typically five hours.

3. When the Model 197A is in use on line power, the battery charger maintains a trickle charge on the battery pack.

NOTE

The IEEE options (Model 1972A and Model 1973A) do not run off of battery power.

2.4 FRONT AND REAR PANEL FAMILIARIZATION

Figure 2-1, Figure 2-2 and the following paragraphs, provide a brief description of the display, front panel controls, input terminals, and rear panel switches.

2.4.1 Display

The Model 197A has a 5-1/2 digit liquid crystal display (LCD) that includes a switch selectable electrolumines-



Figure 2-1. Model 197A Front Panel



Figure 2-2. Model 197A Rear Panel

cent backlight. Positive polarity is implied by the absence of the minus (–) sign. The following annunciators are displayed on theLCD.

BAT — Low battery indicator for the Model 1978.

AC — AC selected (DC implied by the absence of the AC annunciator).

mV or V — Millivolts or volts.

Ω, kΩ or MΩ — Ohms, kilohms or megohms.

µ, mA or A — Microamps, milliamps or amps.

RMT (Remote) — Model 197A being controlled over the IEEE-488 bus (Model 1973A or Model 1972A installed).

C — Model 197A in calibration mode.

AUTO — Autorange.

REL — Relative.

dB — Decibel measurement mode.

STO — Data being stored.

RCL — Data being recalled. RCL flashes when buffer is full during logging cycle.

2.4.2 Front Panel Controls

ON/OFF — Pressing this button turns on the Model 197A. Releasing (out) this button turns the instrument off.

REL — (RELATIVE) — This button allows readings to be made with respect to any baseline value. Also allows detailed information on REL.

dB — This button selects the dB function and is used along with the ACV or DCV function. Measurements are made in dBm referenced to 50, 75, 93, 135, 300 or 600Ω (default). REL can be used to make any voltage level the 0dB reference point for dB measurements.

DATA LOGGER and MIN/MAX — 100 reading storage capacity; records data at one of seven selectable rates from 3 reading/second to 1 reading/hour or by manual trigger (r=6). Also detects and stores maximum and minimum readings continuously while in the data logger mode.

1. STO/CLR — Pressing this button initiates the logging sequence. Pressing this button a second time turns off the data logger. For r=6 rate (manual trigger) every time a reading is desired, press the STO/CLR button.
2. RCL — Pressing and holding in this button scrolls the data pointer. To read the data at a certain point, simply release the button. The logged readings are stored in buffer locations 01 to 102. They are depicted on the front panel as follows: Buffer location #1 is represented by n=01.

AC/DC — This button is used along with the volts (V), current (A), and dB functions. Depressing (in) this button selects AC, releasing (out) this button selects DC. AC Ω is invalid condition. See Table 2-1.

V — Depressing this button selects the volts function.

Ω — Depressing this button selects the ohms function. The AC/DC button must be released (out).

A — Depressing (in) this button selects the current function. Up to 2A on red and black input jacks and up to 10A with the black and white input jacks. Refer to paragraph 2.4.3.

RANGE BUTTONS

1. Depressing AUTO button allows volts and ohms to autorange. In current, it selects the 10A range. There is no autorange function for current.
2. Manual ranging is accomplished by depressing the appropriate range button.

2.4.3 Input Terminals

The input terminals are intended to be used with safety shrouded test leads to help minimize the possibility of contact with live circuits. Safety shrouded test leads (Model 1751) are supplied with the Model 197A. Always disconnect all unused test leads from the instrument.

HI and LO INPUT (Red and Black) — Use this pair of terminals for all volt, ohm, milliamp and dB measurements.

10A and LO (White and Black) — Use this pair of terminals for measuring current up to 10A (up to 20A for 15 seconds).

OHMS Sense HI and LO — Use this pair of terminals along with HI and LO input for four wire resistance measurements.

2.4.4 Current Fuse Replacement

The current fuse protects the 200μA through 2000mA ranges from an input current greater than 2A. To replace the current fuse, perform the following steps:

NOTE

The front panel current fuse (F101) is rated at 2A. With a 220,000 count display, the 2A range can momentarily (approx. one minute) read 2.2A before the fuse will blow. This 10% overrange will not harm the instrument.

1. Turn off the power and disconnect the power line and test leads.
2. Place the end of a flat-blade screwdriver into the slot in the fuse holder on the front panel. Press in slightly

and rotate the fuse carrier one quarter turn counterclockwise. Release pressure and remove the fuse carrier and the fuse.

3. Remove the defective fuse and replace it with the following type: 2A, 250V, 3AG, normal-blow (Keithley part number FU-13) or equivalent.

CAUTION

Use only the recommended fuse type. If a fuse with a higher current rating is installed, instrument damage may occur.

2.4.5 Rear Panel Switches

The rear panel of the Model 197A is shown in Figure 2-2. Note that if an IEEE-488 interface module (Model 1972A or 1973A) is installed, a modified top cover (provided with the interface) will be installed. The modified top cover has clearance holes in the rear panel to provide access to the interface connector(s) and switches. Refer to the Model 1973/1972 IEEE-488 Interface Instruction Manual for details.

DISPLAY BACKLIGHT — This pushbutton switch is used to control the electroluminescent display backlight. Placing the switch to the "in" position turns the backlight on and conversely, placing the switch to the "out" position turns it off. In an adequately lighted environment, keep the light off to extend its life.

CALIBRATION — This slide switch is used to enable or disable calibration of the Model 197A. In the ENABLED position, calibration constants can be stored. In the DISABLED position, newly entered calibration constants are lost when the instrument is turned off. During normal operation, keep this switch in the DISABLED position.

LINE VOLTAGE — This slide switch is used to match the insturment to the available line power voltage.

2.5 ERROR MESSAGES

Table 2-1 lists the error messages associated with basic front panel operation. Note that the instrument has a number of other messages that are discussed in the appropriate sections of the manual.

2.6 OPERATING CONDITIONS

2.6.1 Environmental Conditions

All measurements should be made at an ambient temperature within the range of 0°C to 50°C, and with a relative humidity of less than 80% up to 35°C. For ambient above 35°C derate humidity 3% per C up to 50°C. If the instrument has been subjected to extremes of temperatures, allow sufficient time for internal temperature to reach environmental conditions. Typically, it takes one hour to stabilize a unit that is 10°C (18°F) out of the specified temperature range.

2.6.2 Maximum Allowable inputs

Table 2-2 lists the maximum allowable inputs for the Model 197A.

Table 2-1. Error Messages

Display	Message	Comments
0000	RAM Error	Model 197A locks up. See Section 5 for troubleshooting information.
cErr	Calibration Error (NVRAM Failure)	Model 197A locks up, but operation can be restored by pressing any one of the four momentary pushbuttons. If restored, calibration is invalid as indicated by the flashing "C" annunciator. See Section 5 for troubleshooting information.
OL	Overrange	Overrange input applied to the Model 197A. Leading minus sign indicates that input signal has a negative value.
AC Err Ω	Invalid Ω Function	"AC" and "Ω" annunciators flash. Correct problem by releasing (out) AC/DC pushbutton.

Table 2-2. Model 197A Maximum Allowable Inputs

Function	Ranges	Maximum Allowable Inputs
DCV	200mV, 2V	1000VDC or peak AC for less than 10sec per minute 300Vrms continuous.
	20-1000V	1000VDC or peak AC.
ACV	200mV, 2V	750Vrms, 1000V peak for less than 10sec per minute 300Vrms, continuous. 10^7•Hz maximum.
	20-750V	750Vrms, 1000V peak. 10^7•Hz maximum.
DCA, ACA	200µ-2000mA	2A, 250VDC or rms (fuse protected).
	10A	10A continuous; 20A for 15sec (unfused).
Ω	All	450V peak AC or DC, 10 seconds per minute, 350Vrms continuous.

2.6.3 Warm Up

The Model 197A requires one hour for warm up to achieve rated accuracy.

2.7 BASIC BENCH MEASUREMENTS

Basic measurement techniques for using the Model 197A to measure AC and DC volts, resistance, AC and DC current and dB are covered in the following paragraphs. Also included is the operation of the minimum/maximum and 100 point data logger.

WARNING

Before operating the Model 197A, observe all previously mentioned safety precautions. When testing high energy power circuits follow the instructions found in paragraph 2.2. Failure to observe these and other safety precautions mentioned in this manual could result in severe injury or death.

The LO terminal on the Model 197A is designed to float above earth ground to avoid ground loop problems.

WARNING

Hazardous voltage may be applied to the LO terminal. The maximum allowable voltage between the LO terminal and chassis ground is 500V. Destruction of insulation, which could present a shock hazard, may occur if the 500V maximum is exceeded.

CAUTION

Do not exceed the maximum input limits shown in Table 2-2.

2.7.1 Power Up

NOTE

The software revision level of the Model 197A can be displayed upon power up by running the diagnostic program. See Section 5, Maintenance, for more information.

Turn on the Model 197A by pressing in the ON/OFF switch. All zeroes are briefly displayed before going into the measurement mode.

NOTE

If the Model 197A does not enter the measurement mode, refer to paragraph 5.7.1.

2.7.2 Relative Mode

When the relative mode is selected with an on-scale reading on the display the following occurs:

1. The REL annunciator is displayed.
2. The next reading is stored.
3. This reading is algebraically subtracted from all subsequent readings and displayed.

A REL level can be established for any measurement function (Volts, Ohms, Amps and dB) and is effective only on that function. Changing functions will not affect a REL level already established. However, if another REL level is set (on any function) the previous REL level is cancelled. For example, place the Model 197A in the ohms function and select the 200Ω range. Short the test leads and press the REL button. Note that the REL annunciator is on. Select DCV and note that the REL annunciator is off, indicating that there is not a REL level established for DCV. Switch back to ohms and note that the REL level is still there. Again, go to DCV and set a REL level of +1V. The REL annunciator turns on. Switch back to ohms and note that the REL level for ohms is cancelled.

It is important to remember what the REL function does. The REL function establishes a baseline. That baseline is algebraically subtracted from all subsequent readings for that function.

Once a REL level is established for a measurement function, that stored level will be the same regardless of what range the Model 197A is on. For example, if +1V is established as the REL level on the 20VDC range, +1V is also the REL level for other DCV ranges.

The dynamic range of the display is ±400,000 counts. This means that if a REL level of –2.00000V is established, then applying +1.99999V to the input displays +3.99999V. Once the REL level is established, that level is algebraically subtracted from the input signal. For example: if a +1.00000V REL level is established, then applying a +2.00000V level displays a +1.00000V level.

The instrument accepts a ±220,000 count input before going into the overrange condition (OL). For example: –1.00000V REL level is established and 1.50000V is applied. The instrument displays +2.500000V. If the input is 2.20000V the instrument overranges.

2.7.3 DC Voltage Measurement

The Model 197A can make DC voltage measurements between 1μV and 1000V. The basic procedure is as follows:

1. Connect the test leads to the HI and LO INPUT terminals of the Model 197A.
2. Select the DCV function.
3. Select a range consistent with the expected voltage. For automatic range selection, press in the AUTO button.

NOTE

To prolong instrument life, manual ranging is recommended for routine measurements above 200V.

4. Connect the test leads to the source as shown in Figure 2-3. If the positive source terminal is connected to the LO terminal of the instrument, the display shows a negative value. If the negative source terminal is connected to the LO terminal, the display shows a positive value.
5. Observe the display; If the "OL" message is shown, select a higher range until a normal reading is displayed. Always use the lowest possible range for the best resolution.
6. Take the reading from the display.

The term "when properly zeroed" means that the user must establish a proper baseline for subsequent measure-



Figure 2-3. DC Voltage Measurements

ments on that range. To zero the Model 197A use the following procedure:

1. Short the INPUT HI and LO test leads together.
2. Wait until the display reading settles. Noise and thermal emfs may require a few moments to settle out.
3. Press the REL button.

The 200mV DC range and the 200Ω range require zero to be set in order to achieve rated accuracy.

2.7.4 TRMS AC Voltage Measurements

The Model 197A can make TRMS AC voltage measurements between 1μV and 750V. To measure AC proceed as follows:

1. Connect the test leads to the HI and LO terminals of the Model 197A.
2. Select the ACV function.
3. Select a range consistent with the expected voltage. For automatic range selection, press in the AUTO button.
4. Connect the test leads to the source as shown in Figure 2-4.

NOTE
There is a small amount of offset (typically 50 counts or less) present when using the AC function. Do not REL this level out. The reason for this is that the offset is generally negligible as compared to the input signal. For example:

offset = 22μV

applied signal = 20mV

display reading = $\sqrt{(20\text{mV})^2 + (22\mu\text{V})^2}$

$= \sqrt{.0004 + 484 \times 10^{-12}}$

= .0200000121

This offset is seen as the last digit which is not displayed on the Model 197A. Therefore, the offset is negligible.

5. Observe the display, if the "OL" message is shown, select a higher range until a normal reading is displayed. Always use the lowest possible range to obtain the best resolution.
6. Take the reading from the display.

NOTE
See paragraph 2.8 for TRMS considerations. When measuring AC signals disconnect any test leads from the OHMS SENSE terminals.

2.7.5 Microvolt Measurement Considerations

Accuracy Considerations — For sensitive measurements, other external considerations besides the Model 197A will affect the accuracy. Effects not noticeable when working with higher voltages are significant in microvolt signals. The Model 197A reads only the signal received at its input; therefore, it is important that this signal be properly transmitted from the source. The following paragraphs indicate factors which affect accuracy, noise, source resistance, thermal emfs and stray pick-up.

Noise and Source Resistance — The limit of resolution in measuring voltages with the Model 197A is determined



Figure 2-4. TRMS AC Voltage Measurements

by the noise present. The displayed noise of the Model 197A is 1.5μV peak to peak. This noise is inherent in the Model 197A and is the minimum amount present in all measurements. The 1.5μV of noise is due to the instrument voltage noise. The noise at the Model 197A input increases beyond this minimum when the noise current passes through a resistor thus generating a voltage noise. The total noise becomes a function of the source resistance and is given by the equation:

$$n^2 = e_n^2 + (i_n R_s)^2 + e_r^2$$

where
n = total noise input.
e_n = input voltage noise of the Model 197A.
i_n = input current noise.
R_s = parallel combination of source resistance and input impedance.
e_r = Johnson noise of the source resistance.

Even on the most sensitive range, the noise due to the current is not applicable until R_s reaches approximately 1MΩ. Thus, for an R_2 of 0Ω to 1MΩ, the noise at the input is the inherent 1.5μV peak to peak. Beyond 1MΩ the noise due to R_s becomes a limiting factor in the measurement. Therefore, it is recommended that for sensitive measurements R_s be kept relatively low, if possible below 1MΩ.

As an example of determining e_r noise voltage generation (due to Johnson noise of source resistance) assume that the Model 197A is connected to a voltage source with an internal resistance of 1MΩ. At a room temperature of 20°C (293K), the p-p noise voltage generated over a bandwidth of 1Hz will be:

$$e_r = 6.35 \times 10^{-10} \sqrt{R \times f}$$
$$e_r = 6.35 \times 10^{-10} \sqrt{(1 \times 10^6)\,(1)}$$
$$e_r = 0.635\mu V$$

Thus it is clear that optimum microvolt measurements with the Model 197A are possible with source resistance as high as 1MΩ. However, this resolution will not be realized unless shielding is employed.

Shielding — The Model 197A is insensitive to AC voltages superimposed upon a DC signal at the input terminals. However, AC voltages which are extremely large compared with the DC signal may erroneously produce a DC output. Therefore, if there is AC interference, the circuit should be shielded and the shield connected to the Model 197A ground (particularly for low-level sources). Improper shielding can cause the Model 197A to behave in one or more of the following ways:

1. Unexpected offset voltages.
2. Inconsistent readings between ranges.
3. Sudden shifts in reading.

To minimize pick up, keep the voltage source and the Model 197A away from strong AC magnetic sources. The voltage induced due to magnetic flux is proportional to the area of the loop formed by the input leads. Therefore, minimize the loop area of the input leads and connect each signal at only one point.

Thermal EMFs — Thermal emfs (thermoelectric potentials) are generated by thermal differences between two junctions of dissimilar metals. These can be large compared to the signal which the Model 197A can measure. Thermal emfs can cause the following problems:

1. Instability or zero offset is much higher than expected.
2. The reading is sensitive to (and responds to) temperature changes. This can be demonstrated by touching the circuit, by placing a heat source near the circuit or by a regular patten of instability (corresponding to heating and air-conditioning systems or changes in sunlight).
3. To minimize the drift caused by thermal emfs, use copper leads to connect the circuit to the Model 197A. A banana plug is generally sufficient and generates just a few microvolts. A clean copper conductor such as #10 bus wire is about the best for the application. The leads to the input may be shielded or unshielded, as necessary. Refer to Shielding.
4. Widely varying temperatures within the circuit can also create thermal emfs. Therefore, maintain constant temperatures to minimize these thermal emfs. A cardboard box around the circuit under test also helps by minimizing air currents.
5. The REL control can be used to null out constant offset voltages.

2.7.6 Resistance Measurements

The Model 197A can make resistance measurements between 1mΩ and 220MΩ. The 2MΩ, 20MΩ and 200MΩ ranges autorange when the MΩ button is selected. The Model 197A provides automatic selection of 2-terminal or 4-terminal resistance measurements. This means that

if the ohms sense leads are not connected, the measurement is done 2-terminal. If the sense leads are connected the measurement is done 4-terminal. For 4-terminal measurements, rated accuracy can be obtained as long as the maximum lead resistance does not exceed the values listed in Table 2-3. For 2-terminal or 4-terminal measurements on the 200Ω range, zero must be set by the REL function to obtain rated accuracy. For best results, on the 200Ω, 2kΩ and 20kΩ ranges, it is recommended that 4-terminal measurements be made to eliminate errors caused by the voltage drop across the test leads that occurs when 2-terminal measurements are made. To make resistance measurements, proceed as follows:

1. Connect the test leads to the HI and LO INPUT terminals. If four-wire measurements are to be made, connect an additional set of leads to the OHMS SENSE terminals.

NOTE
The Model 1641 Kelvin test lead kit is ideal for low resistance 4-terminal measurements.

2. Select the ohms function.
3. Select a range consistent with the expected resistance. If desired, use the autorange mode for automatic range selection.
4. If readings are to be made on the 200Ω range, zero the instrument to obtain rated accuracy. To zero the instrument for resistance measurements: Short the test leads together after disconnecting them from the measured circuit. If 4-wire measurements are to be made, short all four test leads as shown in Figure 2-5, allow the reading to settle then press the REL button.
5. For 2-wire measurements connect the instrument as shown in Figure 2-6. For 4-wire measurements, use the connections shown in Figure 2-7.



Figure 2-5. Four Terminal Zeroing

CAUTION
The maximum input voltage between the HI and LO INPUT terminals is 450V DC or peak AC for 10 seconds per minute, 350V RMS continuous. Do not exceed these values or instrument damage may occur. Table 2-3 shows the current output for various resistance ranges.

CAUTION
Incorrect readings will result if the resistance being measured is part of a live circuit.

6. Take the reading from the display.

NOTE
It is helpful to shield resistance greater than $10^6\Omega$ (1MΩ) if a stable reading is expected. Place the resistance in a shielded enclosure and electrically connect the shield to the LO input terminal of the Model 197A.

Table 2-3. Resistance Ranges

Range	Resolution	I-Short	Max V Across Unknown	Maximum Test Lead Resistance for <1 Count Error (Ω)
200	1mΩ	2mA	0.5V	10
2 k	10mΩ	2mA	4.0V	32
20 k	100mΩ	400μA	4.0V	100
200 k	1 Ω	40 μA	4.0V	320
2M	10 Ω	4 μA	4.0V	1K
20M	100 Ω	400 nA	4.0V	3.2K
200M	10 kΩ	400 nA	5.0V	10K



Figure 2-6. Two Terminal Resistance Measurement



Figure 2-7. Four Terminal Resistance Measurement

2.7.7 Current Measurements (DC or TRMS AC)

The Model 197A can make DC or TRMS AC current measurements between 1nA and 10A (20A for 15 seconds). If the expected current level is in question, make the initial measurement on the 10A range. This helps prevent inadvertent blowing of the 2A current fuse which is located on the front panel.

NOTE

For routine measurements above 10A it is recommended that the Model 1651 50A shunt be used.

1. For current measurements between 2000mA and 20mA.
   A. Connect the test leads to the 10A and LO terminals of the Model 197A. Refer to Figure 2-8.

NOTE

The test leads used must be rated to handle 20A. Twist the wires as shown in Figure 2-8 to help in minimizing external fields which could affect the Model 197A or other equipment. Also, keep the test leads as short as possible to minimize voltage drop.

   B. Select the ACA or DCA function.
   C. Select the 10A range. The amps functions does not autorange.
   D. Connect the test leads to the current source as shown in Figure 2-8 and take the reading from the display.

NOTE

Up to 5A may be applied continuously without degradation of the measurement due to self heating effects. Above 5A derate 0.15% rdg per amp for self heating, refer to specifica-



Figure 2-8. Current Measurement Between 2000mA and 20A

tions that precede Section 1. For currents between 10A and 20A, specified accuracy can only be obtained when measurements are limited to a maximum of 15 seconds.

2. For current measurements up to 2000mA:
   A. Connect the test leads to the INPUT HI and LO terminals of the Model 197A.
   B. Select the ACA or DCA function.
   C. Select an appropriate range for the expected current. The current function does not autorange.
   D. Connect the test leads to the current source as shown in Figure 2-9. If an overrange indication is displayed, select a higher range until a normal reading is shown. Use the lowest possible range to obtain the best resolution.
   E. Take the reading from the display.

2.7.8 AC Plus DC Measurements

Use the Model 197A to measure TRMS on a signal which has both AC and DC components.

1. Measure and record the TRMS AC component as described in paragraph 2.7.4.
2. Measure and record the DC component as described in paragraph 2.7.3.
3. Compute the rms value from the following equation:

$$E_{rms} = \sqrt{E^2_{DC} + E^2_{AC}}$$



Figure 2-9. Current Measurements up to 2000mA

2.7.9 dB Measurements

The dB function makes it possible to compress a large range of readings into a much smaller scope. The relationship between dB and voltage can be expressed by the following equation.

$$dB = 20 \log \frac{V_{IN}}{V_{REF}}$$

Tables 2-4 and 2-5 list the dB specifications for DC volts and AC volts.

Table 2-4. dB Specifications for DC Volts (600Ω Ref)

Linear Counts	Resolution	Accuracy
10-99	1dBm	±2dBm typical
100-999	0.1dBm	±1dBm
1000-9999	0.01dBm	±0.1dBm
10000-220,000	0.01dBm	±0.02dBm

The Model 197A can make dB measurements referenced to one of six selectable impedances. The selectable reference impedances are listed in Table 2-6. dB measurements referenced to other (non-selectable) impedances can also be done. One method is to use the relative (REL) feature. REL can also be used to make dB measurements independent of impedance.

Table 2-6. Selectable Reference Impedances

Reference Impedances
600Ω*
300Ω
135Ω
93Ω
75Ω
50Ω

*Power-up default impedance

The basic procedure for placing the instrument in the dB mode is to first select AC or DC volts and then press the dB button. The currently selected dB reference impedance will then be displayed briefly and the dB annunciator will turn on. Note that on power up, the reference impedance will default to 600Ω. To exit from the dB mode, again press dB, or press the Ω or A function button.

dBm Measurements with Selectable Reference Impedances

dBm is defined as decibels above or below a 1mW reference. The default reference impedance (on power-up) of the Model 197A is 600Ω. With this reference impedance, the Model 197A is designed to read 0dBm when the voltage needed to dissipate 1mW through a 600Ω impedance is applied. That calculated voltage level is 0.7764V as derived from the basic power equation:

Table 2-5. dB Specifications for AC Volts (600Ω Ref)

dB Mode (Ref: 600Ω)		Accuracy (±dBm)			
Range	Input	20Hz-10kHz	10kHz-20kHz	20kHz-50kHz	50kHz-100kHz
200mV	1mV to 2mV (-58 to -52dBm)	2.00	3.00	—	—
	2mV to 20mV (-52 to -32dBm)	0.85	1.10	2.00	—
	20mV to 200mV (-32 to -12dBm)	0.18	0.18	0.28	0.65
2V-750V	200mV to 750V (-12 to +59.8dBm)	0.18	0.18	0.28	0.50

$E = \sqrt{P \bullet R}$

$E = \sqrt{10^{-3}\ W \bullet 600\Omega}$

$E = 0.77456V$

Thus with a 600Ω reference impedance the Model 197A will read 0dBm whenever 0.7746V is applied.

NOTE

Do not confuse reference impedance with input impedance. The input impedance of the instrument is not modified in the dB mode.

To make dBm measurements referenced to one of the selectable impedances, proceed as follows:

1. Connect the test leads to the INPUT HI and LO terminals of the Model 197A.
2. Select the ACV or DCV function.
3. Select autorange for optimum resolution.
4. Press and hold the dB button to scroll through the selectable reference impedances (see Table 2-6) Release the button when the desired reference impedance is displayed.
5. Connect the test leads to the voltage source.
6. Make the dBm reading from the display.

dBm Measurements with Other Non-Selectable Reference Impedances

dBm measurements can be made with other reference impedances. The most convenient method for using other reference impedances is to algebraically subtract the calculated dB offset for the desired reference impedance from the reading on the display of the Model 197A Table 2-7 lists common reference impedances and the corresponding offset values. The following equation can be used to calculate the offset for impedances not listed in Table 2-7.

$$\text{Offset (for dBm)} = 10 \log \frac{\text{New ref Z}}{600\Omega}$$

To make dBm measurements referenced to a non-selectable impedance, proceed as follows:

1. Choose the desired reference impedance.
2. Calculate or look up the offset value in Table 2-7 for the desired reference impedance.
3. Determine dBm at the desired reference impedance as follows:

   dBm (at ref Z) = 197A reading – offset

   Example: Make dBm measurements references to a 100Ω reference impedance.

Table 2-7. Levels for Other Reference Impedances

Reference Impedance (Ω)	Reference Voltage Level for 0dBm	0dBW	Offset (600Ω Ref) 0dBm	0dBW
8	0.0894	2.828	–18.75	11.25
50	0.2236		–10.79	
75	0.2739		– 9.03	
93	0.3050		– 8.10	
135	0.3674		– 6.49	
150	0.3873		– 6.03	
300	0.5477		– 3.01	
600	0.7746		0.00	
1000	1.0000		2.22	

$V_{ref.}$ for 0dBm = $\sqrt{10^{-3}W \bullet Z_{REF}}$

$V_{ref.}$ for 0dBW = $\sqrt{Z_{REF}}$

$$\text{Offset (for dBm)} = 10 \log \left(\frac{Z_{REF}}{600\Omega} \right)$$

$$\text{Offset (for dBW)} = 10 \log \left(\frac{Z_{REF}}{600\Omega} \right) - 30\text{dB}$$

A. 100Ω not listed in Table 2-7 so the offset must be calculated as follows:

$$\text{Offset} = 10 \log \left(\frac{100\Omega}{600\Omega}\right)$$

$$\text{Offset} = -7.78\text{dB}$$

B. Subtract –7.78 from all subsequent displayed readings on the Model 197A.

dBm measurements, referenced to another impedance, can be read directly from the display of the Model 197A by utilizing the REL feature, and an accurate voltage source. The basic procedure is as follows:

1. Calculate or look up the equivalent voltage level (Table 2-7) for 0dBm at the desired reference impedance.
2. Input that voltage level to the Model 197A.
3. With the Model 197A in the dB mode, press the REL button.
4. dBm measurements referenced to the desired impedance can now be read directly from the display of the Model 197A.

dBW Measurements

dBW is defined as decibels above or below a one watt reference. The procedure is the same as that found in paragraph 2.7.9 step 2. The only difference is that the reference point is 0dBW (1W) rather than 0dBm (1mW).

dBV Measurements

dBV is defined as decibels above or below 1V (0dBV point). This is a voltage relationship independent of impedance. The basic procedure is to simply subtract 2.22dB (Table 2-7) from all subsequent displayed readings on the Model 197A.

Relative dB Measurements

Just about any voltage level within the measurement limit of the Model 197A can be established as the 0dB point. The basic procedure is to establish the level as the 0dB point by using REL and making the desired dB measurement.

2.7.10 dB Measurement Considerations and Applications

1. Typical Instrument Performance
   Typically, the Model 197A will perform better than its published dB specification. The following example will illustrate this point:
   A. Using the Model 197A in the dB mode (600Ω ref) measure a 1mV RMS, 1kHz source (common application in the communications field). Typically, the Model 197A will read –57.7dBm.
   B. The calculated dBm level for that source is –57.8dBm.
   C. The 0.1dBm error is considerably better than the ±2dBm specification. The specifications are intended to cover worst measurement conditions.
2. Measuring Circuit Gain/Loss
   Any point in a circuit can be established as the 0dB point. Measurements in that circuit are then referenced to that point expressed in terms of gain (+dB) or loss (–dB). To set the 0dB point:
   A. Place the Model 197A in volts, autorange and dB.
   B. Connect the Model 197A to the desired location in the circuit.
   C. Press the REL button. The display will read 0dB.
   D. Gain/Loss measurements can now be made referenced to the 0dB point.
3. Measuring Bandwidth
   The Model 197A can be used to determine the bandwidth of an amplifier as follows:
   A. Connect a signal generator to the input of the amplifier.
   B. Set the Model 197A to ACV and autorange.
   C. Connect the DMM and a frequency counter to the load of the amplifier.
   D. Adjust the frequency of the signal generator until a peak AC voltage reading is measured on the Model 197A.
   E. Press the dB button and then press the REL button. The 0dB point is now established.
   F. Increase the frequency input until the Model 197A reads –3.00dB. The frequency measured on the frequency counter is the high end limit of the bandwidth.
   G. Decrease the frequency input until the dB reading again falls to –3dB. The frequency measured on the signal generator is the low end limit of the bandwidth.
4. Determining Q
   The Q of a tuned circuit can be determined as follows:
   A. Determine the center frequency and bandwidth as explained in paragraph 2.7.10 step 3.
   B. Calculate Q by using the following formula:

$$Q = \text{Center Frequency} / \text{Bandwidth}$$

2.7.11 MIN/MAX and 100 Point Data Logger Operation

The data logger can store up to 100 readings and store the minimum and maximum readings recorded during the period that the data logger is active. The 100 points of data are stored at one of seven selectable rates from three per second to one reading per hour. Also, manual triggering is available (r=6). In the r=6 mode, one reading is stored every time the STO/CLR button is pressed. Readings for minimum and maximum are sampled at the rate of three per second regardless of the selected rate. The procedure for operating the data logger is as follows:

1. Connect the desired measurement configuration to the Model 197A. Make sure that the controls of the Model 197A are set appropriately.
2. Logging Data:
   A. Press and hold the STO/CLR button. The following reading rates will scroll on the display:

      rate/meaning
      r=0 (every reading)
      r=1 (1 rdg/sec)
      r=2 (1 rdg/10 sec)
      r=3 (1 rdg/min)
      r=4 (1 rdg/10 min)
      r=5 (1 rdg/hour)
      r=6 (1 rdg every time STO/CLR is pressed)

      NOTE
      There is no need to select a rate if just minimum/maximum readings are desired. Press the STO/CLR button to start the logger.

   B. Release the STO/CLR button when the desired reading rate is displayed. The STO annunciator turns on and data is logged at the selected rate.
   C. In the manual trigger mode (r=6), a reading is stored every time the STO/CLR button is pressed. The following sequence takes place after the STO/CLR button is pressed when in the manual trigger mode.
      a. The Model 197A stores the reading.
      b. The buffer location number is briefly displayed. For example: Buffer location #1 is represented by n=01.
      c. The Model 197A displays the applied signal and waits for the next manual rigger.

      NOTE
      The logging cycle can be terminated at any time by pressing the STO/CLR button. This shuts off the data logger. However, data is retained and can be recalled at any time as long as the instrument remains on. In the r=6 mode, press the RCL and the STO/CLR button to terminate the data logger cycle.

In the store mode (STO annunciator on) and when the buffer is full (100 readings stored), the minimum and maximum readings are continuously updated. When the store mode is turned off the minimum and maximum readings are not updated.

3. Data Retrieval — Data can be retrieved at any time, but a flashing RCL annunciator indicates that the maximum number of readings (100) have been stored.
   A. Press and hold in the RCL button. The display scrolls through the data points and MIN/MAX (LO/HI). The first data point displayed is the last stored reading. The next two data points are the HI and LO readings made during that logging cycle. Notice that the longer the RCL button is held in the faster the data points scroll on the display.
   B. Release the RCL button at the desired data point and note the reading (data) on the display. The data pointer can be incremented by steps of one by momentarily holding in the RCL button.

2.7.12 Diode Test

The 2kΩ and 200kΩ ranges can be used for testing semiconductor junctions as follows:

1. Select the ohms function.
2. Press the 2k and 200k button (diode symbols) in simultaneously.
3. Display reads forward V drop of a silicon diode at 1.6mA (1.1mA for an LED), up to 2.2V. Red terminal is positive. Accuracy is typically better than 1.5% of reading.

2.8 TRMS CONSIDERATIONS

Most DMMs actually measure the average value of an input waveform but are calibrated to read its RMS equivalent. This poses no problems as long as the waveform being measured is a pure, low distortion sine wave. For complex, nonsinusodial waveforms, however, measurements made with an averaging type meter can be grossly inaccurate. Because of its TRMS (True Root Mean Square) measuring capabilities, the Model 197A provides accurate AC measurement for a wide variety of AC input waveforms.

2.8.1 AC Voltage Offset

Typically, the Model 197A displays 50 counts or less of offset on AC volts with the input shorted. This offset is caused by amplifier noise and offset of the TRMS converter. This offset does not affect the reading accuracy and should not be zeroed out using the REL feature. Refer to paragraph 2.7.4 step 4.

2.8.2 TRMS Measurement Comparison

The RMS value of a pure sine wave is equal to 0.707 times its peak value. The average value of such a waveform is 0.637 times the peak value. Thus, for an average-responding meter, a correction factor must be designed in. This correction factor, K, can be found by dividing the RMS value by the average value as follows:

$$K = \frac{0.707}{0.637} = 1.11$$

By applying this correction factor to an averaged reading, a typical meter can be designed to give the RMS equivalent. This works fine as long as the waveform is a pure sine wave, but the ratios between RMS and average values of different waveforms are far from constant, and can vary considerably.

Table 2-8 shows a comparison of common types of waveforms. For reference, the first waveform is an ordinary sine wave with peak amplitude of 10V. The average value of this voltage is 6.37V, while its RMS value is 7.07V. If we apply the 1.11 correction factor to the average reading, it can be seen that both meters will give the same reading, resulting in no error in the average type meter reading.

The situation changes with the half-wave rectified sine wave. As before, the peak value of the waveform is 10V, but the average value drops to 3.18V. The RMS value of this waveform is 3.86V, but the average responding meter will give 3.53V (3.18 x 1.11), creating an error of 11%.

A similar situation exists for the rectified square wave, which has an average value of 5V and an RMS value of 7.07V. Here, the average responding meter gives a reading of 5.55V 95 x 1.11), while the Model 197A gives a TRMS reading of 5V. Other waveform comparisons can be found in Table 2-8.

2.8.3 Crest Factor

The crest factor of a waveform is the ratio of its peak value to its RMS value. Thus, the crest factor specifies the dynamic range of a TRMS instrument. For sinusodial waveforms, the crest factor is 1.414. For a symmetrical square wave, the crest factor is unity.

The crest factor of other waveforms will, of course, depend on the waveform in question because the ratio of peak to RMS value varies. For example, the crest factor of a rectangular pulse is related to its duty cycle; as the duty cycle decreases, the crest factor increases. The Model 197A has a crest factor of 3, which means the instrument gives accurate TRMS measurements of rectangular waveforms with duty cycles as low as 10%.

2.8.4 Extended Frequency Response

Figure 2-10 illustrates the extended frequency response of the ACV ranges up to 1MHz.



Figure 2-10 Typical ACV Frequency Response

Table 2-8. Comparison of Average and TRMS Meter Readings

Waveform	AC Coupled Peak Value	RMS Value	Average Responding Meter Reading	AC Coupled TRMS Meter Reading	Averaging Meter Percent Error
Sine 	10V	7.07V	7.07V	7.07V	0%
Half-Wave Rectified Sine	10V	5.00V	3.53V	5.00V	29.4%
Full-Wave Rectified Sine	10V	7.07V	7.07V	7.07V	0%
Square 	10V	10.00V	11.10V	10.00V	11%
Rectified Square Wave 	10V	5.00V	5.55V	5.00V	11%
Rectangular Pulse 	10V	$10V \bullet \sqrt{\eta}$	$11.1V \bullet \eta$	$10V \bullet \sqrt{\eta}$	$(1.11V \sqrt{\eta} - 1)$ y 100%
Triangular Sawtooth	10V	5.77V	5.55V	5.77V	3.8%

SECTION 3
Performance Verification

3.1 INTRODUCTION

This section contains information necessary to verify that the Model 197A's performance is within specified accuracy. Model 197A specifications may be found at the front of this manual. Ideally, performance verification should be performed when the instrument is first received to ensure that no damage or change in calibration has occurred during shipment. The verification procedure may also be performed whenever instrument accuracy is suspect or following calibration. If performance on any of the ranges or functions is inconsistent with specifications, calibration should be performed as described in Section 5.

NOTE
If the instrument does not meet specifications and it is still under warranty (less than 12 months since date of shipment), contact your Keithley representative or the factory to determine the action to be taken.

3.2 ENVIRONMENTAL CONDITIONS

All measurements should be made at an ambient temperature between 18°C and 28°C (65°F to 82°F) with a relative humidity less than 80%.

3.3 RECOMMENDED TEST EQUIPMENT

Equipment for verifying the performance of the Model 197A is listed in Table 3-1. Alternate equipment may be used as long as equipment accuracy is at least equal to the specifications listed in Table 3-1.

NOTE
The verification limits in this section only reflect the specifications of the Model 197A. They do not include test equipment tolerance.

3.4 INITIAL CONDITIONS

Before performing the verification procedures, make sure the Model 197A meets the following conditions:

1. If the instrument has been subjected to temperature below 18°C (65°F) or above 28°C (82°F), allow sufficient time for the instrument to reach temperatures within the range. Generally, it takes one hour to stabilize an instrument that is 10°C (18°F) outside of this range.
2. Turn on the Model 197A and allow it to warm up for one hour. The instrument may be operated from either line power of battery pack power, as long as the battery pack has been fully charged as described in paragraph 2.3.3.

Table 3-1. Equipment Specifications

Mfg	Model	Description	Specifications
Fluke	343A	DC Voltage Calibrator	200mV, 2V, 20V, 200V, 1000V ranges ±0.005%
Fluke	5200A	AC Voltage Calibrator	200mV, 2V, 20V, 100V, 50Hz to 10kHz ±0.05%
Valhalla	2500E	AC-DC Current Calibrator	200µA, 2mA, 20mA, 200mA, 2000mA, 10A ranges ±0.03% DC, ±0.1% AC to 5kHz (at full scale)
Fluke	5450A	Resistance Calibrator	100Ω, 1kΩ, 10kΩ, 100kΩ ranges ±0.05%; 1mΩ range ±0.01%; 10MΩ range ±0.05%; 100MΩ ±0.5%
Fluke	5215A	Power Amplifier	1000V range: 10Hz-30Hz ±0.12%; 50kHz-100kHz ±0.10%; 100V max @ 100kHz = 10^7VHz; 750V max @ ≈13kHz = 10^7VHz

3.5 VERIFICATION PROCEDURE

The following paragraphs give the basic verification procedure for the following functions DC volts, AC volts, resistance and current.

WARNING

The maximum common-mode voltage (voltage between input low and chassis ground) is 500V peak. Exceeding this value may cause a shock hazard. Some of the procedures in this section may expose the user to dangerous voltages. Use standard safety precautions when such dangerous voltages are encountered.

3.5.1 DC Voltage Accuracy Check

1. Select the DC volt function and autorange.

CAUTION

Do not exceed 1000V between the input HI and LO terminals or damage to the instrument may occur.

2. Connect the calibrator to the instrument as shown in Figure 3-1.
3. Set the calibrator to 0V and enable the relative mode. Leave the relative mode enabled for all DCV measurements. Check to see that the reading is 000.000V ±1 count.
4. Apply a positive 200mV to the HI and LO INPUT terminals. The reading must be within the limits specified in Table 3-2.
5. For each remaining range, apply the required voltage as specified in Table 3-2 and verify that the reading is within specifications.
6. repeat all checks with negative voltage.



Figure 3-1. Connections for DCV Verification

Table 3-2. Limits for DC Voltage Verification

197A DCV Range	Applied DC Voltage	Allowable Readings (18°C to 28°C)
200mV	200.000mV	199.965 to 200.035
2 V	2.00000 V	1.99976 to 2.00024
20 V	20.0000 V	19.9968 to 20.0032
200 V	200.000 V	199.968 to 200.032
1000 V	1000.00 V	999.83 to 1000.17

3.5.2 AC Voltage Accuracy Check

CAUTION
Do not exceed 750V RMS, 1000V peak

10^7VHz between HI and LO INPUT terminals or instrument damage may occur.

1. Select the AC volts function and autorange. Do not use REL to zero the offset in this procedure. Refer to paragraph 2.7.4 step 4.
2. Connect the AC calibrator to the HI and LO INPUT terminals of the Model 197A as shown in Figure 3-2.
3. Set the calibrator to output 2.00000V at a frequency of 50Hz. Verify that the reading is within the limits specified in Table 3-3.
4. Repeat the 2.00000V AC measurement at the other frequencies specified in Table 3-3.
5. Check the 20V, 200V and 750V ranges by applying the required voltage and frequencies specified in Table 3-3 and verifying that the readings are within the specified limits.

Table 3-3. Limits for AC Voltage Verification

197A AC Range	Applied AC Voltage	20Hz	50Hz	10kHz	20kHz	50kHz	100kHz
200mV	200.000mV	197.900 to 202.100	199.200 to 200.800	198.600 to 201.400	196.750 to 203.250	189.600 to 210.400	189.600 to 210.400
2 V	2.00000V	1.97900 to 2.02100	199.200 to 2.00800	1.98600 to 2.01400	1.96750 to 2.03250	1.93600 to 2.06400	1.93600 to 2.06400
20 V	20.0000V	19.7900 to 20.2100	19.9200 to 20.0800	19.8600 to 20.1400	19.6750 to 20.3250	19.3600 to 20.6400	19.3600 to 20.6400
200 V	200.000V	197.900 to 202.100	199.200 to 200.800	198.600 to 201.400	196.750 to 203.250	193.600 to 206.400	*
750 V	750.000V	739.63 to 760.37	745.25 to 754.75	740.50 to 759.50	*	*	*

*Exceeds the V•Hz product.



Figure 3-2. Connections for ACV Verification

3.5.3 Resistance Accuracy Check

Resistance verification is performed by connecting known, precise resistance values to the HI and LO input terminals and checking to see that the displayed reading is within the required limits. Measurements on the 200Ω, 2kΩ and 20kΩ ranges will be done using the 4-terminal configuration to minimize errors due to the voltage drop across the test leads.

CAUTION

Do not exceed 450VDC or peak AC for 10 seconds per minute, 350V rms continuous between the HI and LO INPUT terminals or the instrument might be damaged.

1. Select the ohms function (AC/DC button must be out) and the 200Ω range.
2. Use Kelvin test leads (e.g. Keithley Model 1641) in the input HI and LO, and then OHMS SENSE HI and LO terminals. Short the leads together. Enable the relative (REL) mode. Check to see that the display reads 000.000. Leave the relative mode enabled for the remaining resistance measurements.
3. Connect the 190Ω calibration resistor as shown in Figure 3-3. Note that the 4-terminal configuration is used for this measurement.
4. Check to see that the displayed reading is within the limits specified in Table 3-4.
5. Connect a 1.9kΩ calibration resistor to the instrument as shown in Figure 3-3. Switch the instrument to the 2kΩ range. Verify that the displayed reading is within the limits specified in Table 3-4.
6. Connect a 19kΩ calibration resistor to the instrument as shown in Figure 3-4. Switch the instrument to the 20kΩ range. Verify that the displayed reading is within the limits specified in Table 3-4.
7. Connect a 190kΩ calibration resistor to the instrument as shown in Figure 3-4. Switch the instrument to the 200kΩ range. Verify that the displayed reading is within the limits specified in Table 3-4. Note that the 2-terminal configuration may be used on the 200kΩ and higher ranges.
8. Continue with each of the calibration resistance values listed in Table 3-4. Be sure to place the Model 197A on the correct range for each measurement. The remaining readings may be done using 2-terminal configuration.

Table 3-4. Limits for Resistance Verification

197A Range	Applied Resistance	Allowable Readings (18°C to 28°C)
200	190.000 Ω	189.959 to 190.041
2 k	1.90000 kΩ	1.89964 to 1.90036
20 k	19.0000 kΩ	18.9949 to 19.0051
200 k	190.000 kΩ	189.949 to 190.051
2M	1.90000MΩ	1.89931 to 1.90069
20M	19.0000MΩ	18.9770 to 19.0230
200M	190.000MΩ	186.199 to 193.801



Figure 3-3. Connections for 200Ω, 2kΩ and 20kΩ Range Verification (4-terminal)



Figure 3-4. Connections for 200kΩ through MΩ Ranges Verification (2-terminal)

3.5.4 DC Current Accuracy Check

DC current accuracy is checked by connecting a calibrated DC current source to the HI and LO INPUT terminals for up to 2000mA (10A and LO terminals for 2000mA through 10A). The accuracy is then verified by referring to Table 3-5 which shows the exact number of counts allowed in order to remain in the limit of the specifications.

CAUTION
Do not exceed 2A to the HI and LO INPUT terminals or the front panel amps fuse will blow. Refer to paragraph 2.4.4.

1. Select the DC current function. Select the 2000mA range.
2. Connect the instrument to the DC current calibrator as shown in Figure 3-5. The HI side of the AMPS terminal should be connected to the HI terminal and the LO side of the calibrator output should be connected to LO.
3. Set the calibrator to 00.000 and enable the relative (REL) mode.
4. Verify that the displayed reading is within the limits specified in Table 3-5.
5. Switch the Model 197A to the 20mA range. Set the calibrator to output +20.0000mA. Verify that the displayed reading is within the limits specified in Table 3-5.
6. Switch the Model 197A to the 200mA range. Set the calibrator to output +200.000mA. Verify that the displayed reading is within the limits specified in Table 3-5.
7. Switch the Model 197A to the 2000mA range. Set the calibrator output +2000.00mA. Verify that the reading is within the limits specified in Table 3-5.
8. Set the Model 197A to the 10A range. Connect the DC current to the 10A and LO terminal as shown in Figure 3-6.

NOTE
Be sure to connect the calibrator to the 10A and LO terminals. Otherwise, applying the 5A (as specified in Table 3-5) would blow the front panel current fuse.

9. Apply +0.50000VDC to the current calibrator to output 5.0000A. Verify that the reading is within the limits specified in Table 3-5.
10. Repeat steps 1 through 10 with negative current.



Figure 3-5. Connections for DC Current Verification (200µA to 2000mA)



Figure 3-6. Connections for DC Current Verification (2000mA to 20A)

Table 3-5. Limits for DC Current Verification

197A DC Range	Applied DC Current	Allowable Readings (18°C to 28°C)
200µA	200.00µA	199.785 to 200.215
2mA	2.00000mA	1.99785 to 2.00215
20mA	20.0000mA	19.9785 to 20.0215
200mA	200.000mA	199.585 to 200.415
2000mA	2000.00mA	1995.85 to 2004.15
10 A	5.0000 A	4.9735 to 5.0265

3.5.5 AC Current Accuracy Check

AC current accuracy is checked by connecting a calibrated AC current source to the HI and LO INPUT terminals for 200µA to 2000mA, 10A and LO terminals for 2000mA to 20A, and then verifying that the displayed reading is within the specified range.

CAUTION

Do not exceed 2A between the HI and LO INPUT terminals or instrument damage might occur. Refer to paragraph 2.4.4.

1. Select the AC current function on the Model 197A. Place the instrument in the 2000mA range.
2. Connect the AC calibrator to the Model 197A as shown in Figure 3-7. Set the calibrator frequency to 1kHz. Do not use the relative mode to zero the offset in the AC mode.
3. Set the calibrator to output 200.000µA and switch the Model 197A to the 200µA range. Verify that the displayed reading is within the limits specified in Table 3-6.
4. Change the Model 197A to the 2mA range. Set the calibrator to output 2.00000mA. Verify that the displayed reading is within the limits specified in Table 3-6.
5. Change the Model 197A to the 20mA range. Set the calibrator to output 20.0000mA. Verify that the displayed reading is within the limits specified in Table 3-6.
6. Change the Model 197A to the 200mA range. Set the calibrator to output 200.000mA. Verify that the displayed reading is within the limits specified in Table 3-6.
7. Change the Model 197A to the 2000mA range. Set the calibrator to output 2000.00mA. Verify that the displayed reading is within the limits specified in Table 3-6.
8. Connect the calibrator to the Model 197A 10A and LO terminals as shown in Figure 3-8. Change the Model 197A to the 10A range.



Figure 3-7. Connections for AC Current Verification (200µA to 2000mA)





Figure 3-8. Connections for AC Current Verification (2000mA to 10A)

NOTE
Be sure to connect the calibrator to the 10A and LO terminals. Otherwise, applying the 5A (as specified in Table 3-6) would blow the front panel current fuse.

9. Set the calibrator to output 5.0000A. Verify that the displayed reading is within the limits specified in Table 3-6.

Table 3-6. Limits for AC Current Verification

197A AC Range	Applied AC Current	20Hz	50Hz	10kHz	30kHz
200µA	200.000µA	197.900 to 202.100	198.300 to 201.700	195.750 to 201.250	195.750 to 204.250
2mA	2.00000mA	1.97900 to 2.02100	1.98300 to 2.01700	1.95750 to 2.04250	1.95750 to 2.04250
20mA	20.0000mA	19.7900 to 20.2100	19.8300 to 20.1700	19.5750 to 20.4250	19.5750 to 20.4250
200mA	200.000mA	197.900 to 202.100	198.300 to 201.700	198.300 to 201.700	—
2000mA	2000mA	1979.00 to 2021.00	1983.00 to 2017.00	1983.00 to 2017.00	—
10A	5.0000 A	4.9150 to 5.0850	4.9400 to 5.0600	4.9400* to 5.0600	—

* Not to exceed 1kHz

SECTION 4
Theory of Operation

4.1 INTRODUCTION

This section contains an overall functional description of the Model 197A. Information pertaining to the Model 1978 Battery Pack option is also included. Detailed schematics and component layout drawings are located at the end of this instruction manual.

4.2 OVERALL FUNCTIONAL DESCRIPTION

The Model 197A is a 5-1/2 digit DMM with five AC and DC voltage ranges, seven resistance ranges and six AC and DC current ranges. A simplified block diagram of the Model 197A is shown in Figure 4-1. The heart of the Model 197A is the A/D converter that translates the conditioned analog input signal into a form usable by the microcomputer.

4.3 ANALOG CIRCUITRY

The following paragraphs contain a description of the input multiplexer, buffer amplifier, +2V reference and A/D converter circuits. These circuits may be found on schematic diagram number 197A-106 located at the end of this manual.

4.3.1 Multiplexer

The multiplexer connects one of four signals to the buffer amplifier: signal, zero, reference and ohms reference. The multiplexer, shown in Figure 4-2, is made up of 4 JFETs which are controlled by the microprocessor through U114. The FETs are driven by drivers U103 and U112. The drivers convert the digital signals of the microprocessor to signals usable by the FETs.

Note that the particular FET used to sense zero on DCV is range dependent. This is done so that zero may be sensed in a manner that eliminates the errors due to the ON resistance of Q106 and Q109. It also reduces errors due to leakage current of U102.

Ordinarily, FET switching creates transients which could be seen in the final measurement. These effects are minimized in the Model 197A through the use of software generated delays.

4.3.2 Input Buffer Amplifier

The input buffer amplifier provides the necessary isolation between the input signal and the A/D converter. The amplifier is a noninverting, low noise, high impedance circuit with X1 or X10 gain. The amplifier gain is controlled by the microprocessor and is range and function dependent. Figure 4-3 shows the simplified schematic of the input buffer amplifier. The gain is X10 when Q116 is ON and X1 when Q116 is OFF.



Figure 4-1. Simplified Block Diagram

4.3.3 2V Reference Source

The Model 197A voltage and current measurements are based on comparing the unknown signal with an internal 2V reference voltage. During each measurement cycle the unknown is sampled along with a zero measurement and a 2V reference measurement to compute the unknown voltage.

The 2V reference is made up of a highly stable zener diode (VR103), an op-amp and a resistive divider. U109 and R125C, D, and E act as a constant current source to minimize the zener voltage variations. R121D, E and F is then used to divide down the 6.4V zener voltage of 2V.

The output of U109 is buffered by Q122 to form a +10V supply.



Figure 4-2. JFET Multiplexer

4.3.4 Input Signal Conditioning

For DCV and ACV the signal conditioning is performed by R103, R104, R105 and their shunt capacitors. Range switching is performed by K101, K102, K103, Q105, Q106 and Q109. Q107 and Q108 are used to sense zero in a manner that eliminates the errors due to the on resistance of Q106 and Q109. The FETs are driven by U112.

The following attenuation is provided:

÷ 1 is used on the 200mV and 2V ranges.
÷ 10 is used on the 20V range.
÷ 100 is used on the 200V range.
÷ 1000 is used on the 1000V/750V range.

Protection for the AC and DC voltage functions is provided by Q103, Q114, Q115, Q127, CR102, CR104, R106, R107 and R113. R106 and R107 are used exclusively on the 200mV and 2V ranges of DCV to limit current to Q114 and Q115. R113 is used exclusively on the 200mV and 2V ranges of ACV to limit current to CR102 and CR104.

Signal conditioning for current is performed by R112, R118 and R123 current shunts. For DC current measurements the shunt voltage drop (220mV full range) is applied directly to the input signal FET for conversion. In AC current, the shunt voltage drop is treated as a <220mV AC signal and is switched to the AC converter section. Overload clamping occurs at 3 diode drops



Figure 4-3. Simplified Schematic of the Input Buffer Amplifier

which is a level high enough to permit high crest factor current waveforms.

In DCV the properly scaled signal is applied directly to Q111 through R106, R107 and C109. In ACV the scaled signal is applied to the AC converter for transformation to a DC signal that is applied to Q111.

Resistance measurements are made using the ratiometric technique (see Figure 4-4). When the resistance function is selected, a series circuit is formed between the ohms source, a reference resistor, and the external unknown resistance. An ohms source of 4.3V is obtained by placing a protection diode (CR101) in series with a +5V supply and the ratiometric network. A current then flows through the reference resistor and the unknown resistance. Since this current is common to both resistances, the value of the unknown resistance can be calculated by measuring the voltage across the reference resistor and the voltage across the unknown resistance.



Figure 4-4. Input Configuration During 2- and 4-Terminal Resistance Measurements

The following ohms reference resistors are used (see Figure 4-5).

R103 | | R105A | | R105B (1kΩ) on 200Ω and 2kΩ ranges
R105D | | R105A | | R105B (10kΩ) on 20kΩ range
R105C | | R105A | | R105B (100kΩ) on 200kΩ range
R105A | | R105B (1MΩ) on 2MΩ range
R105A (10MΩ) on 20MΩ and 200MΩ ranges

By measuring the four inputs to the A/D converter the unknown resistance can be computed by the microprocessor using this equation:

$$RX = \frac{R^{REF} \bullet (V\Omega \text{ SENSE HI} - V\Omega \text{ SENSE LO})}{V\Omega \text{ REF HI} - V\Omega \text{ REF LO}}$$

For the 200Ω range VΩ SENSE HI and VΩ SENSE LO are actually multiplied by a factor of 10 in the buffer circuit.

Protection on the ohms ranges is accomplished by RT101, Q101 and Q102. For an input voltage applied to the Ω input terminals, Q101 and Q102 clamp the voltage to the reference resistors to a safe limit. RT101 limits the current to Q101 and Q102. R105A provides protection of the ohms source by limiting current.

The Model 197A is equipped to make 2- or 4-terminal resistance measurements. Generally, 4-terminal measurements should be made on the 200Ω range because the relatively large output current can develop a significant voltage across the test leads, affecting instrument accuracy.

Figure 4-4 shows the equivalent circuit of the input circuit. R_X is the unknown measured resistance and R1, R2, R3 and R4 represent the test lead resistance. R2 and R3 are connected only during 4-terminal measurements. When using a 2-terminal configuration, all the current flows through the test leads R1 and R4. If R_X has a low value, the amount of voltage developed across the test leads can be significant. Since the voltage is sensed across the combined resistance of R_1, R_x and R_4; considerable error can be introduced into the reading. To use a 4-terminal connection, a second set of leads (R2 and R3) are connected to the unknown resistance. The amount of current through R2 and R3 is much smaller than the current through R1 and R4. Thus, the voltage seen by the instrument is much closer to the actual value across the measured resistance, minimizing the error.



Figure 4-5. Resistance Measurement Simplified Circuit

4.3.5 A/D Converter

The Model 197A uses a combination constant frequency variable pulse width, charge balance, single slope analog-to-digital converter. A simplified schematic of the A/D used in the Model 197A is shown in Figure 4-4 with an associated waveform. Refer to schematic 197-106 for detailed component location.

The charge balance phase begins when the input enable/disable line is set high. This occurs at the end of a software-generated delay period that allows the signal to settle after appropriate multiplexer FET is turned on.

Once this occurs, an offset is added to the signal from the buffer to convert it to a negative unipolar input to the integrator. The signal from the buffer has a range of –2.2V to +2.2V on the volts and amps functions, and 0V to +4V on the ohms function. Therefore, it is necessary to have a larger offset on the ohms function. This is done by switching in R117B.

The integrator (comprised of Q121, U110 and C123) ramps up until it just passes the charge-balance comparator threshold voltage. When the rising edge of Q3 (U119) occur $\overline{Q1}$ of U117A goes high forcing I_{CB} into the integrator input. The time $\overline{Q1}$ of U117A remains high depends upon the state of comparator U108B when Q3 (U119) goes high. Thus, the amount of I_{CB} fed back to the integrator input will be proportional to the input voltage. Each time the output U117A goes high it is gated (inside the microprocessor) with the microprocessor's internal clock and pulses are counted. Once U117A goes low the process repeats itself.

The charge balance phase continues for 100msec. At the end of the charge balance phase, the output of the integrator is testing at some positive voltage. Since the integrator output is connected tot he noninverting input of

the U108A, its output will stay high until the integrator ramps negative. During single slope Q120 is turned off and R129 is connected to +5V. The single slope comparator is then gated with the microprocessor's internal clock and counted. Once the comparator output goes low the microprocessor stops counting and can complete the reading.

4.3.6 AC Converter

On the 200mV AC range the input is routed through U104 for a X5 voltage amplification. The gain stage is used to permit accurate voltage measurements at higher frequencies and lower input levels. On all other ranges U104 is configured for a gain of X1. The gain of U104 is controlled by the microprocessor. The output of U104 is applied tot he TRMS converter chip, U106, which converts the AC input signal to the corresponding DC level. The DC output is then applied to the signal FET.

4.4 DIGITAL CIRCUITRY

Model 197A operation is controlled by the internal microcomputer. This section briefly describes the operation of the various sections of the microcomputer and associated digital circuitry. For more complete circuit details refer to schematic diagram number 197-106 at the end of this manual.

4.4.1 Microcomputer

The microcomputer centers around the 146805E2 CMOS microprocessor. It is an 8 bit microprocessor with direct addressing of up to 8k bytes on a shared address and data bus.

Timing of the microprocessor is accomplished by the use of Y101; 1 3.2768MHz crystal. Internally this frequency is divided down by 5 to obtain a bus operating frequency of 655.36kHz. This is present on the address strobe of U124 (pin 6) and supplies timing to all other parts of the instrument through the binary divider U119.

The software for the MPU is stored in U122 (PROM). Temporary storage is provided by U121. U121 is used to share the calibration constants on power up and as RAM for the microprocessor's in-house functions. It also stores readings for the data logger. U113 is the NVRAM and is used to store the calibration constants.



Figure 4-6. A/D Converter

4.4.2 Address Decoding

U123 is used to latch in the address that is on the bus when the address strobe of U124 goes high and presents it to the PROM (U122) during data strobe.

4.4.3 PIA

U114 provides for most of the control of the instrument. It controls all ranging hardware, A/D converter, and data output and input for the IEEE option.

4.4.4 Display Board

The LCD display is driven by a flat pack LCD controller chip U201 and it communicates to the microprocessor through 4 control lines. During power-up the microprocessor configures U201 to drive the triplexed display.

In order to drive the display correctly four voltages are obtained from R134. The clock required by U201 is obtained from U119.

The display board also houses the special function keys; dB, REL, STO/CLR and RCL.

4.5 DIGITAL CALIBRATION

The Model 197A uses digital calibration to eliminate all potentiometers in the instrument to facilitate calibration. The constants that the Model 197A uses are stored in a nonvolatile electrically alterable, read-only memory (U113), and are read on power-up of the instrument. There is one constant for each range on DCV, ACV and Ω, except for the 750VAC range which uses the constant from the 2V range. On the DCA and ACA functions the 200mV AC constants are used respectively.

4.6 POWER SUPPLY

Fuse F102 is the LINE FUSE which is internally accessible. S101 is the power on/off switch and S102 selects 115V or 230V operations by placing the transformer primary windings in parallel or series.

T101, the power transformer has two secondary windings; one for the Model 197A and the other for the Model 1972A Analog Output/IEEE option or the Model 1973A IEEE option. The bridge rectifier (CR107) functions as a fullwave rectifier for both the plus and minus supplies. R131 limits current to the 15V zener (VR104) and to the batteries (if installed) for charging. VR104 acts as a pre-regulator to the +10V supply. R132 limits current to the 15V zener VR105. VR105 acts as a pre-regulator to the –9V supply.

4.7 MODEL 1978 BATTERY OPTION

Maximum battery charging rate is achieved when the instrument is connected to line power and the on/off switch is off. Fullwave rectified voltage from CR107 is applied to R102 and BT101 to charge the batteries. Q101 acts as a current sink if the charging current rises above 150mA. The batteries are of the quick recharge type and will charge in 8 to 10 hours. With the instrument turned on the batteries will trickle charge at approximately 40mA.

With the battery pack installed, the negative supply is generated using a CMOS voltage inverter (U101). The output of the inverter is applied to CR101 and C101 for filtering.

Low battery detection is accomplished by the comparator (U102) and the microprocessor. A voltage level of 11.6V across BT101 signals and end of useful battery life. The trip level for the comparator is set by R103 and R104.

4.8 ELECTROLUMINESCENT DISPLAY BACKLIGHT

An electroluminescent panel is incorporated to enhance the display under low light conditions. U202 is a DC to AC converter for the backlight. Rear panel switch S104 turns the backlight on (in position) and off (out position).

SECTION 5
Maintenance

5.1 INTRODUCTION

This section contains installation, service and calibration information for the Model 197A and Model 1978. Fuse replacement, line voltage selection and troubleshooting procedures are also included in this section.

WARNING

The procedures described in this section are intended for use by qualified service personnel only. Do not perform these procedures unless qualified to do so. Many of the steps covered in this section expose the individual to potentially lethal voltages that could result in personal injury or death if normal safety precautions are not observed.

5.2 DISASSEMBLY INSTRUCTIONS

If it is necessary to troubleshoot the instrument, replace a component, or install an option, use the following disassembly procedure. Disassembly should be done in order that it s presented since, in general, each step depends on a previously performed procedure. Most parts referred to in the following steps are shown in Figure 5-1.

WARNING

Disconnect the line cord and any test leads from the instrument.

Top Cover Removal

1. Turn off the power, disconnect the line cord and remove all test leads from the terminals of the Model 197A.
2. Turn the unit over and remove the four screws from the bottom of the case.
3. Turn the unit over again and separate the top cover from the rest of the unit

NOTE

When reinstalling the top cover, make sure to properly position the tilt-bail/handle into the bottom cover.

IEEE-488 Interface Removal (If Installed)

The interface board is secured to the mother board by the 6-pin male connector (P1008) and a rear standoff. To remove the interface board, gently lift it upward until it separates from the connector and the standoff.



Figure 5-1. Model 197A Miscellaneous Parts

Battery Pack Removal (If Installed)

The Model 1978 battery pack is mounted on top of the mother board top shield. Perform the following steps to remove the complete shield/battery pack assembly:

1. Disconnect the battery pack ribbon cable connector from P1009 on the mother board.
2. Remove the one screw that secures the top shield to the mother board. The screw is located at the rear of the shield.
3. Carefully remove the shield/battery pack assembly from the unit.

Display Board Removal

1. Disconnect the display board ribbon cable from the mother board at J/P1006.
2. Disconnect the input leads from the input jack terminals. Table 5-1 provides terminal identification for reassembly.
3. Remove the front panel assembly from the unit.
4. The display board assembly is secured to the front panel with three screws. remove these three screws and separate the display board assembly from the front panel.
5. The LCD (liquid crystal display) assembly is secured to the display board by five tabs. To remove, gently push the tabs away from the display board and pull the LCD assembly away from the display board. The phosphor layer of the electroluminescent backlight will remain intact with the display board. An exploded view of the display assembly is shown in Figure 5-2.

Table 5-1. Input Terminal Identification

Input Terminal	Conductor Insulator Color
INPUT HI	Red
INPUT LO	Black
Ω SENSE HI	Orange
Ω SENSE LO	Grey
10A INPUT	White

Mother Board Removal

1. Disconnect the AC power receptacle from the mother board at J/P1007.
2. Remove the four case spacers.
3. Carefully lift the mother board out of the bottom case cover.

WARNING

When reinstalling the mother board, make sure the two switch guards are installed on the rear panel CALIBRATION and LINE VOLTAGE slide switches. These switch guards block openings in the rear panel preventing access to hazardous voltage.

5.3 BATTERY PACK (Model 1978) INSTALLATION

Refer to Figure 5-1 and perform the following procedure to install the battery pack:

WARNING

Disconnect the line cord and remove all test leads from the terminals of the Model 197A.

1. Remove the top cover as explained in paragraph 5.2.
2. Remove the shield.
   A. Remove the screw that secures the shield to the mother board. The screw is located at the rear of the shield.
   B. Carefully pull up on either side of the shield.
   C. Lift the shield out of the Model 197A.
3. Position the battery board as shown in Figure 5-1 and secure it to the shield using the two supplied screws. The screws are positioned through the shield into the battery board fasteners.
4. Place the battery pack in the bracket and position on the shield as shown. Route the two screws through the shield into the bracket and tighten.

CAUTION

Do not allow the battery leads to short together or damage to the batteries may occur.

5. Connect the red battery lead to the +RED terminal pin on the battery board. Connect the black battery lead to the –BLK terminal pin on the battery board.

CAUTION

Be careful not to reverse the wires (NOTE: Reds to Red and Black to Black).



Figure 5-2. Display Assembly Exploded View

6. Carefully place the shield (with battery pack) back into the Model 197A so that it seals properly on the two spacers. Replace retaining screw in the shield.

NOTE
The retaining screw on the rear of the shield also serves to connect the shield to circuit LO.

7. Connect the ribbon cable from the battery board to P1009 on the mother board. make sure pin 1 on the cable connects to pin 1 of P1009. Refer to the detailed drawing of Figure 5-1.

CAUTION
Make a close visual inspection of the connections to ensure that they are properly connected. Otherwise, damage to the instrument may result.

8. Reinstall the top cover as explained in paragraph 5.2.

NOTE
The IEEE Interface options do not run off of battery power.

5.4 LINE VOLTAGE SELECTION

The Model 197A may be operated from either 105V-125V or 210V-250V, 50-60Hz. A special transformer may be installed for 90-110V or 195-235V operation. The instrument was shipped from the factory set for an operating voltage marked on the front panel. To change the line voltage, proceed as follows:

1. Turn off the Model 197A and disconnect it from line power.
2. Set the LINE VOLTAGE switch on the back of the instrument to correspond to line voltage available. Example: 110VAC is available, set the switch to 105V-125V.

CAUTION
Connect only to the line voltage selected. Application of incorrect voltage can damage the instrument.

3. Plug the power cord into a properly grounded outlet.

WARNING

Ground the instrument through a properly grounded receptacle before operation. Failure to ground the instrument can result in severe injury or death in the event of a short circuit or malfunction.

5.5 FUSE REPLACEMENT

WARNING

Disconnect the instrument from the power line and from other equipment before replacing fuses.

5.5.1 Line Fuse Replacement

The line fuse is located internally in the Model 197A. For exact fuse location refer to Figure 5-1. To replace the fuse proceed as follows:

1. Remove the top cover as explained in paragraph 5.2.
2. If the Model 1973A or Model 1972A IEEE-488 interface is installed, it must be removed to gain access to the fuse. The IEEE board secured to the mother board by a support post at the rear and connector P1008. To remove, lift the board up until it disengages from the connector and support post.
3. Replace the blown fuse with the following type: 1/8A, 250V, 3AG, Slo-Blo (Keithley Part Number FU-20)

CAUTION

Do not use a fuse with a higher rating than specified or instrument damage may occur. If the instrument persistently blows the fuse, a problem may exist within the instrument. If so, the problem must be corrected before operation may continue.

4. If the IEEE interface was installed, reinstall the interface as follows:
   A. Install the rear standoffs.
   B. Position the interface board above the rear standoffs.

WARNING

Do not push down on J1008. The male connector pins will pass through J1008 and may cause personal injury.

   C. Guide the terminals of P1008 and firmly push down on that end of the board to mate the connectors.
   D. Push down on the other side of the interface board until it snaps onto the rear most standoff. make sure the board is properly seated on the other two standoffs.
   E. Reinstall the modified top cover.
5. Reinstall the top cover as explained in paragraph 5.2.

5.5.2 Current Fuse Replacement

The current fuse protects the 200μA through 2000mA ranges from an input current greater than 2A. To replace the current fuse, perform the following steps:

1. Turn off the power, disconnect the power line and remove the test leads.
2. Place the end of a flat blade screwdriver into the slot of the fuse holder on the front panel. Carefully press in and rotate the fuse carrier one-quarter turn counterclockwise. Release pressure, remove the fuse and the fuse carrier from the front panel.
3. Remove the defective fuse and replace it with the following type:

   2A, 250V, 3AG, normal blow (Keithley Part Number FU-13) or equivalent.

CAUTION

Use only the recommended fuse type. If a fuse with a higher current rating is installed, instrument damage may occur upon overload.

5.6 FRONT PANEL CALIBRATION

Calibration should be performed every 12 months, or if the performance verification procedures in Section 3 show that the Model 197A is out of specification. If any of the calibration procedures in this section cannot be performed properly, refer to the troubleshooting information in this section. If the problem persists, contact your Keithley representative or the factory for further information.

NOTE

ACA and DCA do not need to be calibrated. These current ranges are calibrated when ACV is calibrated.

5.6.1 Recommended Calibration Equipment

Calibration may be performed using the equipment listed in Table 5-2. Alternate calibration equipment may be used as long as the equipment's accuracy is at least as good as the specifications listed in Table 5-2.

5.6.2 Environmental Conditions

Calibration should be performed in an ambient temperature of 23°C ±3°C and a relative humidity of less than 70%. If the instrument has been subject to temperature outside of this range, or to higher humidity, allow at least one additional hour for the instrument to stabilize before beginning the calibration procedure.

5.6.3 Calibration Switch

The Model 197A is shipped from the factory with its external calibration switch in the DISABLED position. In this position, calibration constants cannot be stored when entered from the front panel or over the IEEE-488 bus. The switch must be moved to ENABLED to allow calibration constant storage.

The calibration switch is located in the middle of the rear panel. Slide the switch to ENABLED. Plug in the line cord and turn on the instrument. Press in the REL and dB pushbuttons simultaneously until the message "CAL" is displayed. Release the buttons. The unit is now in calibration as indicated by the "C" annunciator.

WARNING

Some procedures require the use of high voltage. Take care to prevent contact with live circuits which could cause electrical shock resulting in injury or death.

NOTE

Calibration may be stopped at any time and if desired, only selected ranges may be calibrated.

5.6.4 DC Voltage Calibration

Select the DCV function. Connect the DC calibrator to the Model 197A as shown in Figure 5-3.

NOTE

The following procedure must be performed in the exact sequence listed.

1. Press the REL and dB buttons simultaneously until the message "CAL" is displayed. Release the buttons. The Model 197A is now in the calibration mode.

Table 5-2. Recommended Calibration Equipment

Description	Required Minimum Specifications	Mfr.	Model No.
DV Voltage Calibrator	200mV, 0.003°% + 0.5µV 2V, 0.003°% + 0.5µV 20V, 0.003°% + 0.5µV 200V, 0.003°% + 0.5µV 1000V, 0.003°% + 0.5µV (90 day accuracy)	Fluke	5440
AC Voltage Calibrator	200mV, 2V, 20V, 200V and 750V ranges, ±0.05%	Fluke	5200A & 5215A
Resistance Calibrator	190Ω, 50ppm 1.9kΩ, 50ppm 19kΩ, 50ppm 190kΩ, 50ppm 1.9MΩ, 100ppm 19MΩ, 500ppm (90 day accuracy)	Fluke	5450A



Figure 5-3. DC Voltage Calibration Configuration

The calibration mode is indicated by the "C" annunciator on the front panel display.

2. Select the 200mV range, short INPUT HI and LO, and press the REL button (REL annunciator is on).
3. Set the calibrator to output +190.000mV.
4. Adjust the display to read 190.000 with the use of the STO/CLR and RCL buttons. The STO/CLR button increments the displayed reading. The RCL button decrements the displayed reading. The longer either button is held in, the faster the displayed reading is modified.
5. Select the next range (2V) and set the calibrator output to +1.90000V.
6. Repeat step 4 to read 1.90000.
7. Reverse the calibrator leads in order to output –1.90000V.
8. Repeat step 4 to read –1.90000.
9. Repeat steps 2 through 4 for the remaining DC voltage ranges listed in Table 5-3.

Table 5-3. DC Voltage Calibration

Range	Calibrator Voltage	Model 197A Reading
200mV	+190.000mV	190.000mV
2 V	+1.90000 V	1.90000 V
2 V	–1.90000 V	–1.90000 V
20 V	+19.0000 V	19.0000 V
200 V	+190.000 V	190.000 V
1000 V	+1000.00 V	1000.00 V

5.6.5 AC Voltage Calibration

With the Model 197A still in the calibration mode ("C" annunciator on), connect the AC voltage calibrator to the Model 197A as shown in Figure 5-4. Steps 1-6 must be performed in the exact sequence listed.

1. Select the AC voltage function and the 200mV range.
2. Set the calibrator to output 190.000mV at 500Hz.
3. Adjust the display using the STO/CLR and RCL buttons to read 190.000mV AC.
4. Press the dB button and verify that the dB annunciator is displayed.
5. Set the calibrator to output 19.000mV at 500Hz.
6. Adjust the displayed reading for 19.000mV.
7. Press the REL button and verify that the dB annunciator is off.
8. Repeat steps 2 and 3 for the remaining ranges using Table 5-4 as a guide.
9. Store the new cal constants before proceeding. See paragraph 5.6.8.

5.6.6 Frequency Compensation

The following section is to be used to determine if frequency compensation should be performed on the Model 197A, and to perform frequency compensation if necessary. This procedure requires the Model 197A to be warmed up for at least one hour. Note that this section is not to be used to verify that the Model 197A AC Voltage function is within specifications. If desired refer to Section 3 Performance Verification.

WARNING

Steps 1 through 4 require the use of high voltage. Take care not to come into contact with live circuits that could cause personal injury or death.



Figure 5-4. AC Voltage Calibration Configuration

1. Select the 750VAC range and set the calibrator to output 500.00V at 500Hz. Press the REL button (REL annunciator turns on).
2. Set the calibrator to output 500.00V at 20kHz. Verify that the reading on the Model 197A is 000.00 ±150 counts. Press REL (REL annunciator turns off).
3. Set the calibrator to output 100.00V at 500Hz and select the 200VAC range. Press the REL button (REL annunciator turns on).
4. Set the calibrator to output 100.000V at 20kHz. Verify that the reading on the Model 197A is 000.000V ±200 counts. Press REL (REL annunciator turns off).
5. Set the calibrator to output 10.0000V at 500Hz and select the 20VAC range. Press REL (REL Annunciator turns on).
6. Set the calibrator to output 10.0000V at 20kHz. Verify that the reading on the Model 197A is 00.0000 ±200 counts. Press REL (REL annunciator turns off).

If any of the above verifications are not met by the Model 197A, the top cover must be removed and three trimmer capacitors adjusted. The adjustments must be performed within 10 minutes after the top cover is removed so that the circuit components will be close to normal operating temperature. The three trimmer capacitors (C103, C105 and C107) are accessible through the shield. The shield and PC board must be secured to the bottom cover in order to prevent movement. This assembly can be secured with two screws and nuts (not supplied). Route the screws through the bottom cover through the two brown spacers to the shield. Secure the screws with the nuts. Also, use a flat blade, insulated calibration tool for all the adjustments. Perform the following steps in the exact sequence listed.

WARNING

Steps 1 through 4 require the use of high voltage. Take care not to come into contact with live circuits that could cause personal injury or death.

1. Select the 750VAC range and set the calibrator to output 500.00V at 500Hz. Press the REL button (REL annunciator turns on).
2. Set the calibrator to output 500.00V at 20kHz. Adjust C103 for a reading of 000.00 ±50 counts. Press REL (REL annunciator turns off).
3. Set the calibrator to output 100.00V at 500Hz and select the 200VAC range. Press REL (REL annunciator turns on).
4. Set the calibrator to output 100.00V at 20kHz. Adjust C105 for a reading on the Model 197A of 000.000V ±50 counts. Press REL (REL annunciator turns off).
5. Set the calibrator to output 10.0000V at 500Hz and select the 20VAC range. Press REL (REL annunciator turns on).
6. Set the calibrator to output 10.0000V at 20kHz. Adjust C107 for a reading on the Model 197A of 00.0000V ±50 counts.
7. Reinstall the top cover.

Table 5-4. AC Voltage Calibration

Range	Calibrator Voltage	Calibrator Frequency	Model 197A Reading
200mV	190.000mV	500Hz	190.000mV
200mV*	19.000mV	500Hz	19.000mV
2 V	1.90000 V	500Hz	1.90000 V
20 V	19.0000 V	500Hz	19.0000 V
200 V	190.000 V	500Hz	190.000 V

5.6.7 Resistance Calibration

With the Model 197A in the calibration mode ("C" annunciator on), select the ohms function and connect the calibrator to the Model 197A as shown in Figure 5-5. Four wire resistance measurements need only be done when not using the REL feature. Use the following procedure and refer to Table 5-4 to calibrate the ohms function.

1. Select the 200Ω range and set the resistance calibrator to output zero ohms (short).
2. Press the REL button on the Model 197A. The REL annunciator appears on the display and the display reads zero (test lead compensation).
3. Set the calibrator to output 190Ω. Adjust the display using the STO/CLR and RCL buttons for a reading of 190.000Ω. Press REL (REL annunciator turns off).
4. Select the 2kΩ range and set the resistance calibrator to output zero ohms (short). Press REL (REL annunciator turns on).
5. Set the calibrator to output 1.9kΩ. Adjust the display for a reading of 1.90000kΩ.
6. Press the REL button and note that the REL annunciator turns off.
7. Select the 20kΩ range and set the resistance calibrator output zero ohms (short). Press REL (REL annunciator turns on).
8. Set the calibrator output to 10kΩ. Adjust the display for a reading of 19.0000kΩ. Press REL (REL annunciator turns off).
9. Repeat steps 7 and 8 for the 200k, 2M and 20M ranges using Table 5-5 as a guide. For these ranges use the configuration shown in Figure 5-6.

Table 5-5. Resistance Calibration

Range	Calibrator Voltage	Model 197A Reading
200Ω	190 Ω	190.000 Ω
2kΩ	1.9 kΩ	1.90000 kΩ
20kΩ	19 kΩ	19.0000 kΩ
200kΩ	190 kΩ	190.000 kΩ
2MΩ	1.9 MΩ	1.90000 kΩ
20MΩ	19 MΩ	19.0000MΩ

NOTE
Four terminal resistance measurements need only be done when not using the REL feature.



Figure 5-5. 200, 2k and 20k Four Wire Resistance Calibration



Figure 5-6. 200k, 2M and 20M Two Wire Resistance Calibration

5.6.8 Calibration Storage

To store the calibration constants, simultaneously press the REL and dB buttons until the message "Stor" is displayed. If instead the message "out" is displayed, then calibration storage was not enabled and the calibration constants will only be valid until the Model 197A is turned off. Temporary calubration is denoted by the flashing "C" annunciator.

To save calibration constants after "out" appears on the display, slide the calibration switch to ENABLED. Press REL and dB simultaneously until "CAL" appears on the display. Then simultaneously press REL and dB until "Stor" is displayed. The calibration constants are now stored and the Model 197A is ready for normal operation.

5.7 TROUBLESHOOTING

The troubleshooting instructions contained in this section are intended for use by qualified personnel having a basic understanding of analog and digital circuitry. The individual should also be experienced at using electronic test equipment as well as standard troubleshooting procedures. The information presented here has been written to assist in isolating a defective circuit or circuit section; isolation of the specific component is left to the technician.

The success or failure in troubleshooting an instrument such as the Model 197A depends not only the skill of the technician, but also relies on accurate, reliable test equipment. Table 5-6 lists the required test equipment and specifications recommended for troubleshooting the Model 197A. Other equipment such as logic analyzers, capacitance meters (etc) could also be helpful in difficult situations.

5.7.1 Power Up Sequence

The software revision level of the Model 197A may be displayed upon power-up by running the diagnostic pro-

Table 5-6. Recommended Troubleshooting Equipment

Equipment	Use
Five function DMM with 0,1% basic DCV accuracy 10M input impedance.	Power supply and DC voltage checks; analog signal tracing continuity, logic levels.
Dual-trace, triggered sweep oscilloscope, DC to 50MHz	Digital and analog waveform checks.
Digital Frequency Counter	Checking clock frequencies.

gram. The diagnostic program is explained in paragraph 5.7.2.

When the Model 197A is turned on it goes through a power up sequence that is outlined as follows:

1. Reset — All zeroes are briefly displayed before going into the measurement mode. During this display the Model 197A goes through a check of the RAM circuitry, and a check of the NVRAM circuitry.
2. If the RAM circuitry has a problem, the Model 197A locks up with all zeroes. Refer to Table 2-1.
3. If the NVRAM test fails, the following message is displayed:

   cErr

4. If no problem is found by the RAM and NVRAM checks, the Model 197A goes into the measurement mode.

If the RAM check reveals a problem, check U121. If the NVRAM check reveals a problem, check U113 and refer to 5.7.2 (NVRAM test).

5.7.2 Self Diagnostic Program

The self diagnostic program is designed to aid the technician in troubleshooting the Model 197A. There are several tests that may be performed using the self diagnostic program. These tests (display, software revision level and sequential display test) are run automatically. After this sequence the Model 197A goes into the troubleshooting mode.

To use the self diagnostic program, press and hold in the dB button while turning on the Model 197A. The following sequence occurs:

1. All LCD digits and annunciators turn on.
2. The software revision level is then displayed (e.g. A1).
3. The sequential display test runs.
4. The Model 197A goes into the troubleshooting mode.

If the dB button is released, the instrument flags either RAM or NVRAM self test failures, should they occur. If neither RAM nor NVRAM fails, the instrument defaults to the troubleshooting test mode.

RAM Test — If the RAM test fails, the Model 197A locks up with all zeroes displayed. Replacing U112 may correct the problem.

Non-Volatile RAM Test — If the NVRAM test fails, the following message is displayed:

cErr

This is a message indicating that the instrument is not calibrated properly, since calibration constants are stored in NVRAM. The Model 197A remains at this point if the test fails, but operation may be restored for troubleshooting by pressing either the REL, dB or DATA Logger buttons. The flashing "C" annunciator indicates that the unit failed the NVRAM test.

At this point try calibrating the instrument with the constants already entered by simultaneously pressing REL and dB until the CAL message is displayed. Then release the REL and dB buttons. Simultaneously press the REL and dB buttons again until the STOR message is displayed. If the error is corrected, indicating that the NVRAM is probably good, a full calibration is required. If the error persists try replacing the NVRAM chip, U113. Again the Model 197A must be completely recalibrated after the problem is corrected.

Sequential Display Test — Segments and annunciators are sequentially displayed in eight steps. Use Figure 5-7 for segment identification. The steps are as follows:



Figure 5-7. Segment Identification

1. The "a" segments of the digits, the dB and V annunciators are displayed.
2. The "b" segments of the digits are displayed.
3. The "c" segments of the digits are displayed.
4. The "d" segments of the digits are displayed. Also, the m (mA) RCL and RMT annunciators are displayed.

5. The "e" segments of the digits are displayed. Also, the minus sign, REL, M and Ω annunciators are displayed.
6. The "f" segments of the digits are displayed. Also, the AUTO, BAT, m (mV) and c annunciators are displayed.
7. The "g" segments of the digits are displayed. Also, the AC and k annunciators are displayed.
8. The decimal points, most significant digit and the STO, μ and A annunciators are displayed.

Troubleshooting Test Modes — The troubleshooting mode is designed to switch on various switching FETs, transistors, relays and logic levels to allow signal tracing through the instrument. The first displayed mode reflects the selected function and range. For example: assume that "0u1" is displayed.

In this case,
0 is the test number.
u corresponds to the volts function.
1 corresponds to the 200mV range.

The test number can be changed by pressing in the dB button. Table 5-7 lists test modes for all functions and ranges.

Troubleshooting consists of selecting the desired test mode and using the data found in Table 5-7 to signal trace the circuit.

NOTES:

1. When a different function or range is selected, the dB button must be pressed and held in to update the display with the corresponding test mode.
2. Do not use AUTO when in AC or DC volts.
3. Use AUTO when checking circuitry on the 20M and 200MΩ range (006, 106, 206, 306 and 406).

5.7.3 Power Supply and Battery Pack (Model 1978) Checks

Table 5-8 shows the various checks that can be made to the power supplies of the Model 197A and 1978. In addition to the normal voltage checks, it is a good idea to check the various supplies with an oscilloscope for signs of noise or oscillations.

5.7.4 A/D Converter and Display

Make sure the A/D and display are operating properly BEFORE attempting to troubleshoot the signal conditioning circuits. Check these circuits using the information in Table 5-9 and 5-10.

5.7.5 Signal Conditioning

These circuits can be checked by using the diagnostic program (troubleshooting modes). See paragraph 5.7.2. Also, refer to Table 5-7.

5.8 SPECIAL HANDLING OF STATIC-SENSITIVE DEVICES

CMOS devices are designed to operate at very high impedance levels for low power consumption. As a result, any normal static charge that builds up on your person or clothing may be sufficient to destroy these devices if they are not handled properly. Table 5-11 lists all the static sensitive devices in the Model 197A. When handling these devices, use the following precautions to avoid damaging them.

1. The devices listed in Table 5-11 should be transported and handled only in containers specially designed to prevent static build up. Typically, these devices will be received in static-protected containers. The parts should remain there until ready for installation.
2. Remove the devices from their protective containers only at a properly grounded work station. Always ground yourself with a suitable wriststrap.
3. Handle the devices only by the body. Do not touch the pins.
4. Any printed circuit board into which the device is to be inserted must also be grounded to the bench or workstation.
5. Use on grounded type solder suckers.
6. Use only a grounded type soldering iron.
7. Once the device is installed on the PC board, the device is adequately protected and normal handling may resume.

Table 5-7. Model 197A Troubleshooting Mode

Function and Range	Test Mode	DC Amp Gain U102	AC Amp Gain U102	Multiplexer FET On	Range Transistor On	Range Control Logic Levels On U			
						PA0	PA1	PA2	PA3
200mVDC	0u1	X10		Q111		0	1	1	0
	1u1	X10		Q112		0	1	0	0
	2u1	X1		Q113		0	0	0	1
	3u1	X1		Q112		0	0	0	0
2VDC	0u2	X1		Q111		0	0	1	0
	1u2	X1		Q112		0	0	0	0
	2u2	X1		Q113		0	0	0	1
	3u2	X1		Q112		0	0	0	0
20VDC	0u3	X1		Q111	Q104, Q105	0	0	1	0
	1u3	X1		Q110	Q104, Q105	1	0	0	0
	2u3	X1		Q113	Q104, Q105	0	0	0	1
	3u3	X1		Q112	Q104, Q105	0	0	0	0
200VDC	0u4	X1		Q111	Q104, Q105, Q106, Q107	0	0	1	0
	1u4	X1		Q110	Q104, Q105, Q106, Q107	1	0	0	0
	2u4	X1		Q113	Q104, Q105, Q106, Q107	0	0	0	1
	3u4	X1		Q112	Q104, Q105, Q106, Q107	0	0	0	0
1kVDC	0u5	X1		Q111	Q104, Q105, Q109, Q108	0	0	1	0
	1u5	X1		Q110	Q104, Q105, Q109, Q108	1	0	0	0
	2u5	X1		Q113	Q104, Q105, Q109, Q108	0	0	0	1
	3u5	X1		Q112	Q104, Q105, Q109, Q108	0	0	0	0
200mVAC	0u1	X1	X5	Q111	Q104-Q107, Q118	0	0	1	0
	1u1	X1	X5	Q112	Q104-Q107, Q118	0	0	0	0
	2u1	X1	X5	Q113	Q104-Q107, Q118	0	0	0	1
	3u1	X1	X5	Q112	Q104-Q107, Q118	0	0	0	0
2VAC	0u2	X1	X1	Q111	Q104-Q107, Q118	0	0	1	0
	1u2	X1	X1	Q112	Q104-Q107, Q118	0	0	0	0
	2u2	X1	X1	Q113	Q104-Q107, Q118	0	0	0	1
	3u2	X1	X1	Q112	Q104-Q107, Q118	0	0	0	0
20VAC	0u3	X1	X1	Q111	Q104, Q105, Q106, Q107	0	0	1	0
	1u3	X1	X1	Q112	Q104, Q105, Q106, Q107	0	0	0	0
	2u3	X1	X1	Q113	Q104, Q105, Q106, Q107	0	0	0	1
	3u3	X1	X1	Q112	Q104, Q105, Q106, Q107	0	0	0	0
200VAC	0u4	X1	X1	Q111	Q104, Q105, Q108, Q109	0	0	1	0
	1u4	X1	X1	Q112	Q104, Q105, Q108, Q109	0	0	0	0
	2u4	X1	X1	Q113	Q104, Q105, Q108, Q109	0	0	0	1
	3u4	X1	X1	Q112	Q104, Q105, Q108, Q109	0	0	0	0
750VAC	0u5	X1	X1	Q111	Q104, Q105	0	0	1	0
	1u5	X1	X1	Q112	Q104, Q105	0	0	0	0
	2u5	X1	X1	Q113	Q104, Q105	0	0	0	1
	3u5	X1	X1	Q112	Q104, Q105	0	0	0	0
DCA All Ranges	0A1-0A6	X10		Q111		0	1	1	0
	1A1-1A6	X10		Q112		0	1	0	0
	2A1-2A6	X1		Q113		0	0	0	1
	3A1-3A6	X1		Q112		0	0	0	0
200Ω	0o1	X10		Q113	Q104, Q105	0	1	0	1
	1o1	X10		Q112	Q104, Q105	0	1	0	0
	2o1	X1		Q111	Q104, Q105	0	0	1	0
	3o1	X1		Q110	Q104, Q105	1	0	0	0

Table 5-7. Model 197A Troubleshooting Mode (Cont.)

Function and Range	Test Mode	DC Amp Gain U102	AC Amp Gain U102	Multiplexer FET On	Range Transistor On	Range Control Logic Levels On U			
						PA0	PA1	PA2	PA3
2kΩ	0o2	X1		Q113	Q104, Q105	0	0	0	1
	1o2	X1		Q112	Q104, Q105	0	0	0	0
	2o2	X1		Q111	Q104, Q105	0	0	1	0
	3o2	X1		Q110	Q104, Q105	1	0	0	0
20kΩ	0o3	X1		Q113	Q104, Q105, Q108, Q109	0	0	0	1
	1o3	X1		Q112	Q104, Q105, Q108, Q109	0	0	0	0
	2o3	X1		Q111	Q104, Q105, Q108, Q109	0	0	1	0
	3o3	X1		Q110	Q104, Q105, Q108, Q109	1	0	0	0
200kΩ	0o4	X1		Q113	Q104, Q105, Q108, Q109	0	0	0	1
	1o4	X1		Q112	Q104, Q105, Q108, Q109	0	0	0	0
	2o4	X1		Q111	Q104, Q105, Q108, Q109	0	0	1	0
	3o4	X1		Q110	Q104, Q105, Q108, Q109	1	0	0	0
2MΩ	0o5	X1		Q113	Q104, Q105	0	0	0	1
	1o5	X1		Q112	Q104, Q105	0	0	0	0
	2o5	X1		Q111	Q104, Q105	0	0	1	0
	3o5	X1		Q110	Q104, Q105	1	0	0	0
20M & 200M (Auto)	0o6	X1		Q113		0	0	0	1
	1o6	X1		Q112		0	0	0	0
	2o6	X1		Q111		0	0	1	0
	3o6	X1		Q113		0	0	0	1
ACA All Ranges	0A1-0A6	X1	X5	Q111		0	0	1	0
	1A1-1A6	X1	X5	Q112		0	0	0	0
	2A1-2A6	X1	X5	Q113		0	0	0	1
	3A1-3A6	X1	X5	Q112		0	0	0	0

Table 5-8. Power Supply and Battery Pack (Model 1978) Checks

Step	Item/Component	Required Condition	Remarks
1	S102	Set to 115V or 230V as required	S102 is externally accessible from rear panel.
2	F102 Line Fuse	Continuity	
3	Line Cord	Plugged into proper line receptacle; power on.	
4	Power ON/OFF switch pin 6	+13V to +16.5V	+V power for regulator circuitry.
5	U109 pin 2	+6.4 ±5%	Virtual Reference.
6	U109 pin 3	+6.4 ±5%	Reference Zener.
7	Q126 collector or U116 pin 7	+10V ±10%	+10V Supply.
8	Power ON/OFF switch pin 12	–15V ±10%	–V power for regulator circuitry.
9	U107 pin 2	–6.4V ±10%	Inverting input for U107.
10	U107 pin 3	–6.4V ±10%	Low noise negative supply reference.
11	Q128 Emmitter	–9.0V ±5%	–9V Supply.
12	U116 pin 3	+5V ±5%	+5V Supply reference.
13	U116 pin 2	+5V ±5%	Inverting input for U116.
14	Q126 Emitter	+5.0V ±5%	+5V analog supply.
15**	Q123 Emitter or J1009 pin 7	+5.0V ±10%	+5V digital supply.
16*	Q101 Base	0.6V while charging. Power switch off.	Current Sink
17*	U101 pin 8	>10.8V line cord disconnected, battery packed charged and power on	Voltage Inverter
18*	U102 pin 7	+5 with batteries charged	Voltage Comparator

*Battery option (1978) checks.

**If Q123 is replaced, be sure that the device is properly seated on the mother board so that it will not touch the IEEE board (if installed).

Table 5-9. Display Board Checks

Step	Item/Component	Required Condition	Remarks
1	—	Turn on power; select the 2V range.	
2	P1006, pin 6	+3.3V	Vlcd1
3	P1006, pin 7	+1.66V	Vlcd2
4	P1006, pin 8	+5V ±5%	Power to Display
5	P1006, pin 3	81.92kHz	Clock
6	P1006, pin 2	0V to +5V Pulses	Data From µp.
7	P1006, pin 13	0V to +5V Pulses	Data From µp.
8	P1006, pin 14	0V to +5V Pulses	Data From µp.
9	P1006, pin 15	+5V to 0V Pulses	Data From µp.
10	P1006, pin 1	+4.7V with backlight on	
11	LCD	Verify that the LCD is properly positioned	
12	Connector (P1006)	Check that connector is not reversed.	
13	Strip Connector	Verify that they are positioned properly.	

Table 5-10. A/D Converter/Microcomputer Checks

Step	Item/Component	Required Condition	Remarks
1		Turn on power; select 2VDC range. Short the input.	
2	U124 pin 38	3.276800MHz Clock	Crystal Frequency (Y101).
3	U119 pin 10	655.36kHz Clock	A/D timebase and µP address strobe.
4	U119 pin 6	81.92kHz Clock	Clocks for U117A
5	U119 pin 5	40.96kHz Clock	Minimum pulse generator signal.
6	U119 pin 7	163.84kHz Clock	Generates set for U117A. (proper phase of $\overline{Q4}$ and $\overline{Q3}$ required.
7	U119 pin 12	1.28kHz Clock	Timebase for real time µP interrupt.
8	U118 pin 6	+5V to ≈0V pulse train, 3µsec in duration every 22µsec. (Set signal to end charge balance pulse.)	S1 input of U118B
9	U110 pin 6	Integrator Waveform.	
10	U108B pin7	Variable waveform 0V to +5V.	Comparator Output (Charge Balance)
11	U117 pin 6	Variable pulse train, 0V to +5V.	Charge Balance Current Control
12	U105A pin 15	Variable pulse train, 0V to +5V.	U124 Timer Input
13	U105A pin 10	4msec pulses approximately every 150msec. 0V to +5V	Single Slope Control Line
14	U117B pin 9	50msec and 100msec pulses positive going.	Integrator charge Balance Control

Table 5-11. Model 197A Static Sensitive Devices

Circuit Designation	Keithley Part No.
Q104, Q107	TG-139
Q108, Q110	TG-139
Q,111, 112	TG-139
Q113	TG-139
U101	IC-415
U105	IC-238
U107	IC-347
U113	IC-353
U114	LSI-61
U115	IC-143
U117	IC-337
U118	IC-341
U119	IC-348
U120	IC-351
U121	LSI-62
U122	197A-800-**
U123	IC-338
U124	LSI-60

SECTION 6
Replaceable Parts

6.1 INTRODUCTION

This section contains replacement parts information, component location drawings and schematic diagrams for the Model 197A and Model 1978.

6.2 REPLACEABLE PARTS

Parts are listed alpha-numerically in order of the schematic designation. The first parts list pertains to the Model 197A. The second parts list pertains to the Model 1978 Battery Pack. Figure 5-1 and 5-2 shows miscellaneous parts.

6.3 ORDERING INFORMATION

To place an order, or to obtain information concerning replacement parts, contact your Keithley representative or the factory. See the inside front cover for addresses. When ordering, include the following information:

8. Instrument Model Number
9. Instrument Serial Number
10. Part Description
11. Circuit Designation (if applicable)
12. Keithley Part Number

If an additional instruction manual is required, order the manual package (Keithley Part Number 197A-901-00). The manual package includes an instruction manual and all pertinent addenda.

6.4 FACTORY SERVICE

If the instrument is to be returned to the factory for service, photo copy and complete the service form which follows this section and return it with the instrument.

6.5 SCHEMATIC DIAGRAMS AND COMPONENT LOCATION DRAWINGS

The component location drawings and schematic diagrams, are presented as follows:

Mother Board, Component Location Drawing, Dwg. No. 197A-100.

Mother Board, Schematic Diagram, Dwg. No. 197A-106.

Display Board, Component Location Drawing, Dwg. No. 197A-110.

Display Board, Schematic Diagram, Dwg. No. 197A-116.

Model 1978 battery Pack, Component Location Drawing, Dwg. No. 1978-100.

Model 1978 battery Pack, Schematic Diagram, Dwg. No. 1978-106.

MODEL 197A PARTS LIST

Circuit Design.	Description	Keithley Part No.
	CHOKE	CH-54
C101	CAP, .1UF, 10%, 630V, POLYESTER	C-364-.1
C102	CAP, 1PF, 25%, 1000V CERAMIC	C-367-1P
C103	CAPACITOR	C-184
C104	CAPACITOR	C-362-5600P
C105	CAP, 4-30PF, 500V, VARIABLE	C-358
C107	CAP, 2.5-6PF, 500V, VARIABLE	C-359
C108	CAP, 500PF, .1%,50V, MICA	C-363-500P
C109	CAPACITOR	C-360-.01
C110	CAP,.001UF,10%,100V,POLYPROPYLENE	C-306-.001
C111	CAP, 1UF, 20%,50V POLYESTER	C-350-1
C113	CAP, 15UF, 10%,20V TANTALUM	C-204-15
C114	CAPACITOR	C-366-39P
C115,116,131,138,145,147	CAP,.1UF,20%,50V,CERAMIC	C-237-.1
C117	CAP, 2UF,10%,100V POLYESTER	C-294-2
C118	CAP,1000PF,10%,1000V,CERAMIC	C-64-1000P
C119	CAP,82PF,10%,1000V,CERAMIC	C-64-82P
C120	CAP,15PF,10%,1000V,CERAMIC	C-64-15P
C121,122,128,130	CAP, 10UF,-20+100%,25V,ALUM ELEC	C-314-10
C123	CAP,.0047UF,10%,100V,POLYPROPYLENE	C-306-.0047
C124	CAP,1500UF,-20,+100%,25V,ALUM ELEC	C-314-1500
C125	CAP,22UF,10%,16V,ALUM ELEC	C-361-22
C126	CAP, 2.2UF, 10%, 16V, ALUM ELEC	C-361-2.2
C127	CAP,220UF,-20+100%,25V,ALUM ELEC	C-314-220
C129	CAP,.01UF,20%,500V,CERAMIC	C-22-.01
C132..135,144	CAP,.1UF,20%,50V,CERAMIC	C-365-.1
C136,137	CAP,22PF,10%,1000V,CERAMIC	C-64-22P
C139,140	CAP, 2200PF,20%,500V, CERAMIC	C-22-.0022
C142	CAP, 220P, 5%, 500V, DIPPED MICA	C-236-220P
C146	CAP,220P,10%,1000V CERAMIC	C-64-220P
C148	CAP, .0022UF, 10%, 100V, POLYPROPYLE	C-306-.0022
C149	CAP,1UF,20%,50V, CERAMIC	C-237-1
CR101,103,108,109	DIODE,SILICON,IN4148 (DO-35)	RF-28
CR102,104	RF-60 SELECTION	197-604
CR105	DIODE,BRIDGE,KBP02 (CASE KBP)	RF-36
CR106	DIODE	RF-34
CR107	DIODE,BRIDGE,VM18	RF-52
F101	FUSE, 2A/3AG	FU-13
F102	FUSE, .125A, 250V,3AG SLO-BLO	FU-20
J1001...1005	LUG	LU-111-1
J1006	DISPLAY CABLE SOCKET	SO-65
K101	RELAY, (SPST)	RL-82
K102	RELAY REED	RL-87
K103	RELAY, REED (SPST)	RL-59

P1007	CONN, MALE, MODIFIED	175-316
P1006	CABLE ASSEMBLY	CA-30-5
P1008	IEEE CONNECTOR	175-321
P1009	CONN,DUAL 5-PIN-BERG	CS-389-4
Q101,102	TG-138 SELECTION	197-600A
Q103,127	TG-62 SELECTION	197-602
Q104,107,108,110...113	TRANS, N CHANNEL JFET (TO-92)	TG-139-1
Q105,106,109	TRANSISTOR	TG-176
Q114,115,124,125	TRANS,NPN COMP SILICON AMP,2N5089	TG-62-1
Q116,120	TRANS, N CHANNEL JFET,PN5434(TO-92)	TG-174-1
Q117	TRANS,P CHANNEL JFET,J270 (TO-92)	TG-166
Q118	TRANS,SELECTED N CHANNEL JFET,5434	TG-179
Q119	TRANS,N CHANNEL FET,2N4392 (TO-92)	TG-128-1
Q121	TRANS,N CHANNEL DUAL FET,MP842 (T0-52)	TG-175
Q122	TRANSISTOR	TG-178
Q123	TRANS, HIGH VOLTAGE NPN VERSAWATT	TG-137
Q126	TRANS,NPN SILICON,2N3904 (T0-92)	TG-47
Q128	TRANS,PNP SILICON 2N3906 (TO-92)	TG-84
R101	RES, 1K, 10%, 2W, 100V, FIXED WIREWOUND	R-330-1K
R103	RES, 1K, .05%, 1/10W, METAL FILM	R-390-1K
R104	RES, 1.111M,.1%, .75W, METAL FILM	R-389-1.111M
R105	RES NET, 10M, 1.111M, 110.95K, 10.10	TF-200
R106,107	RES, 180K, 10%, 1/2W, COMPOSITION	R-1-180K
R108,115,102	RES,1M,5%,1/4W, COMPOSITION OR FILM	R-76-1M
R109	RES, 330K, 5%, 1/4, COMPOSITION OR FILM	R-76-330K
R110,111	RES, 330K, 10%, 1/2W, COMPOSITION	R-1-330K
R112	RES NET, 900,90,9,5%	TF-168-2
R113	RESISTOR	R-320-43K
R114	RES,8.25K,1%,1/8W,METAL FILM	R-88-8.25K
R116	RES,200K,5%,1/4W,COMPOSITION OR FILM	R-76-200K
R117	THICK FILM	TF-195
R118	RESISTOR	R-318
R119	RES, 3.01K, 1%, 1/8W, METAL FILM	R-88-3.01K
R120	RES, 800, .1%,1/8W, METAL FILM	R-176-800
R121	THICK FILM	TF-184
R122,124	RES, 220K, 10%, 1/2W, COMPOSITION	R-1-220K
R123	RES, .01, .25%, 1W, WIREWOUND	R-388-.01
R125	THICK FILM	TF-198
R126	RES, 800, .1%,1/8W, METAL FILM	R-176-800
R126	RESISTOR, ZENER DIODE SELECTION	197-601
R127	THICK FILM	TF-196
R128	RES,7.78K,.1%,1/8W, METAL FILM	R-176-7.78K
R129	RES,1M,.1%,1/8W, METAL FILM	R-176-1M
R130	THICK FILM	TF-197
R131	RES, 10, 10%, 2W, COMPOSITION	R-3-10
R132	RES, 330, 10%, 1/2W, COMPOSITION	R-1-330
R133	THICK FILM	TF-199
R134	THICK FILM	TF-194
R135,137	RES,1K,5%,1/4W,COMPOSITION OR FILM	R-76-1K
R136	RES,10M,5%,1/4W,COMPOSITION OR FILM	R-76-10M
R138	RES,3.3K,5%,1/4W, COMPOSITION OR FILM	R-76-3.3K

R139	RES, 22K 5%, 1/4W, COMPOSITION OR FILM	R-76-22K
R140	RES,22,5%,1/4W,COMPOSITION OR FILM	R-76-22
R141	RES,1K,5%,1/4W,COMPOSITION OR FILM	R-76-1K
R142	RES,3.3K,5%,1/4W, COMPOSITION OR FILM	R-76-3.3K
R143	RES,2.2K,5%,1/4W,COMPOSITION OR FILM	R-76-2.2K
R144	RES,47,5%,1/4W,COMPOSITION OR FILM	R-76-47
R145,147	RES,10K,5%,1/4W,COMPOSITION OR FILM	R-76-10K
R146	RES,2K,5%,1/4,COMPOSITION OR FILM	R-76-2K
R148	RES, 15, 5%, 1/4 COMPOSITION OR FILM	R-76-15
RT101	THERMISTER, PTC 250MSEC, 500V, 1220	RT-9-2
S101	SWITCH	SW-448
S102	SWITCH, SLIDE (DPDT)	SW-318
S103	SWITCH, SLIDE (4PDT)	SW-465
S104	FOR DISPLAY BACKLIGHT SWITCH, PUSHBUTTON	SW-410
T101	TRANSFORMER	TR-201
U101	INTEGRATED CIRCUIT	IC-415
U102	IC-165 SELECTED	30167C
U103,112	IC,QUAD COMPARATOR,LM339	IC-219
U104	IC, WIRE BAND JFET INPUT OP-AMP, 4	IC-248-1
U105	IC,TRIPLE 2 CH MULTI/DEMUX,4053	IC-283-1
U106	IC, TRMS TO DC CONVERTER, 637	IC-352
U107	IC, 18V OP-AMP, TLC 271	IC-347-1
U108	IC, DUAL COMP,LM393	IC-343
U109	IC, 18V OP-AMP, 741	IC-42
U110	IC,20V OP-AMP, MP5501CP	IC-414
U111	IC,DARLINGTON ARRAY,2003	IC-206
U113	IC, 16X16 BIT SERIAL RAM, X2443P	IC-353
U114	INTEGRATED CIRCUIT	LSI-61
U115	INTEGRATED CIRCUIT	IC-143
U116	IC,22V OP-AMP,OP02	IC-413
U117	IC,DUAL D-TYPE FLIP FLOP,74HC74	IC-337
U118	IC, TRIPLE 3 INPUT NAND, 74HC10	IC-341
U119	INTEGRATED CIRCUIT	IC-348
U120	IC,QUAD 2 INPUT NAND,74HC00	IC-351
U121	LARGE SCALE IC	LSI-62
U122	PROGRAM	197-800-*
U123	IC, OCTAL D-LATCH W/3 STATE OUT, 7	IC-338
U124	IC, CMOS 8 BIT MICROPROCESSOR, 146	LSI-60
U125	IC,SUPPLY VOLTAGE SUPERVISOR,TL7705AC	IC-602
VR101	DIODE, ZENER 8.2V, IN756A (DO-7)	DZ-61
VR102	DIODE,ZENER 6.44V,IN4577AGED (DO-7)	DZ-58
VR103	DIODE,ZENER 6.4V,IN4579 (DO-7)	DZ-73
VR104	DIODE, ZENER 15V, IN5352 (CASE 17)	DZ-76
VR105	DIODE,ZENER 15V,1N4744A (TO-41)	DZ-75
W1	JUMPER,CIRCUIT	J-3
Y101	CRYSTAL, 3.276800MHZ	CR-21

*Order same firmware as presently installed.

C201	CAP,470UF,20%,6.3V, ALUM ELEC	C-445-470
DS202	ELECTROLUMINESCENT PANEL	DD-48
U201	IC, LCD CONTROLLER/DRIVER, 7225	LSI-59
U202	CONVERTER MODULE	MO-31-1

LTR.	ECO NO.	REVISION	ENG.	DATE
A		PRELIMINARY		
B	[illegible]	RELEASED	CE	8/20/90



NOTES:

1. C124 MUST BE POSITIONED 0.15 (MIN) AWAY FROM T101.
2. C125 MUST BE POSITIONED 0.15 (MIN) AWAY FROM T101.
3. Q123 MUST MAINTAIN 0.2 CLEARANCE FROM P1007 AND IEEE OPTION WHEN MOUNTED HORIZONTALLY. VERTICAL MOUNT IS PREFERRED.
4. ALL PINS TO BE CUT TO A MAXIMUM OF 0.07 FROM SIDE ONE.
5. •6 LKWA MUST BE POSITIONED BETWEEN THE P.C. BOARD AND GROUND CLIP. SEE DETAIL "A".

197A	1
MODEL	NEXT ASSEMBLY / QTY
USED ON	

DO NOT SCALE THIS DRAWING	DIMENSIONAL TOLERANCES UNLESS OTHERWISE SPECIFIED	DATE 8/9/90	SCALE 2:1	TITLE COMPONENT LAYOUT MOTHER BOARD
KEITHLEY KEITHLEY INSTRUMENTS INC. CLEVELAND, OHIO 44139	XX=±.015 ANG.=±1°	DRN. KEK	ENG. APPR. CE	
	XXX=±.005 FRAC.=±1/64	MATERIAL		D NO. 197A-100
	SURFACE MAX. 63	FINISH		

1974-106

ZONE	LTR	ECO NO	REVISION	ENG	DATE
	A		PRELIMINARY		
	B	900823	RELEASED	LB	7/30/90

NOTES:

1. ALL RESISTOR VALUES ARE IN OHMS UNLESS OTHERWISE MARKED (K-KILOHMS, M-MEGOHMS).
2. ALL CAPACITOR VALUES ARE IN MICROFARADS UNLESS OTHERWISE MARKED (pF-PICOFARADS).
3. ALL PUSHBUTTON SWITCHES ARE SHOWN IN THE PUSHBUTTON OUT POSITION.
4. ▽ DENOTES ANALOG COMMON.
5. ▽ DENOTES DIGITAL COMMON.
6. ▽ DENOTES SIGNAL COMMON.
7. ✱ DENOTES FACTORY SELECTED VALUE.
8. ○ DENOTES FRONT PANEL CONTROL.
9. ● DENOTES REAR PANEL MOUNTING.
10. ⊘ DENOTES INTERNAL ADJUSTMENT.
11. **WARNING: R101 IS A FUSIBLE RESISTOR, EXACT REPLACEMENT ONLY.

HIGHEST SCHEMATIC DESIGNATIONS USED			
C149	CR109	F102	J1006
K103	P1009	Q128	R147
RT101	S103	T101	U125
VR105		Y101	

SCHEMATIC DESIGNATIONS NOT USED			
C112	J1001 - J1005	C143	
P1001 - P1006	C141	C106	

PB0 TO U114 PIN 10
PA0 TO U114 PIN 2
PB1 TO U114 PIN 11
PB2 TO U114 PIN 12
PB3 TO U114 PIN 13
PA1 TO U114 PIN 3
PA2 TO U114 PIN 4
PA3 TO U114 PIN 5
PA6 TO U114 PIN 8
PB4 TO U114 PIN 14
PB5 TO U114 PIN 15
} PAGE 2, ZONE A2 / PAGE 2, ZONE A3

TO R117 PIN 1 (PAGE 2, ZONE A1)

MATES WITH J1008 OF IEEE BOARD SEE (972-106)

MATES WITH P1009 OF BATTERY OPTION BOARD (SEE 1978-106)

197A MODEL	NEXT ASSEMBLY	QTY
USED ON		

DO NOT SCALE THIS DRAWING
DIMENSIONAL TOLERANCES UNLESS OTHERWISE SPECIFIED: XX = ± .015, ANG = ± 1°, XXX = ± .005, FRAC = ± 1/64, SURFACE MAX 63
DATE 7-19-90 DRN ENG APPR LB MATERIAL FINISH
SCALE
TITLE SCHEMATIC MOTHER BOARD
KEITHLEY Keithley Instruments Inc. Cleveland, Ohio 44139
D NO 197A-106 SHT. 1 OF 2

BRUNING 44-131-60137 FORM 285118 REV. D

197A-106 ON

ZONE	LTR	ECO NO	REVISION	ENG	DATE
	A		PRELIMINARY		
	B	200823	RELEASED	CB	3/30/90

TO U102 PIN 6 (PAGE 1 ZONE E4)

R117A 17.6K · R117B 51.7K · R117C 28.3K · R117D 10K · R117E 10K · R128 7.78K · S101 · -6.4

Q119 · Q120 · U105B · -9V

+10V · R127C 20K · R127D 20K · C119 82p · Q121 · R127B 31.2K · U110 · C120 15p · R127E 10K · C123 .0047

U105C · R129 1M · N.C. · +5D · -9V

R127G 220K · R127F 3.9K · U108A · R127H 10K · C116 1000P · U108B · R125B 22K

U115C · U118A · U118B · U117A · R127A 7.78K · U117B · U119 · U105A

+5V · R148 10 · S104 · J1006

PAGE 1 ZONE H3 / PAGE 1 ZONE H4 / ⚠PAGE 1 ZONE D5

TO Q117 · TO U112A PIN 9 · TO U112B PIN 5 · TO U112C PIN 7 · TO U112D PIN 11 · TO U103A PIN 9 · TO U103B PIN 5 · TO U103C PIN 7 · TO U103D PIN 11 · TO Q125 · TO U120D PINS 9+10 · TO R133 TO PIN 4

U114 63B21 · R139 22K · P1008 · R134L 22K · P1009 · +5D

U113 2443 · R133A 47K · N.C. · S103 · ENABLE DISABLE · R143 2.2K

TL7705A · C147 0.1 · C144 0.1 · U125 · R134K 22K

R134J 120K · C133 0.1 · C132 0.1 · U120C · R145 2K · TIMER

R134A 22K · R134B 22K · R134C 22K · R134D 22K · R134F 10K · R134G 10K · R134H 10K

MATES WITH P1006 OF DISPLAY BOARD (SEE 197-116)

S1010 · 200V · 1000V · 2V · AUTO · 20V · AC/DC · R135 1K · R137 1K · OS101

U118C · U120B · U115A · U115B · U120A · C131 0.1

U121 6514 · U122 2764 · U123 74HC373 · C134 0.1 · C135 0.1

U124 146805E2

C137 22p · C136 22p · Y101 · R136 10M · OSC OUT · OSC IN · L1 · N.C.

MODEL	NEXT ASSEMBLY	QTY
197A		

USED ON

DO NOT SCALE THIS DRAWING · DIMENSIONAL TOLERANCES UNLESS OTHERWISE SPECIFIED: XX = ± .015, ANG = ±1°, XXX = ± .005, FRAC = ±1/64, SURFACE MAX 63 · DATE 7-1990 · SCALE · DRN · ENG APPR. D.B · MATERIAL · FINISH

Keithley Instruments Inc. Cleveland, Ohio 44139

TITLE SCHEMATIC, MOTHER BOARD

SIZE D · NO 197A-106 · SHT. 2 OF 2

BRUNING 44 131 60137 · FORM 285118 REV. D

LTR.	ECO NO.	REVISION	ENG.	DATE
B	[illegible]	RELEASED	CB	8/30/90



NOTE: FOR MORE COMPONENT INFORMATION
REFER TO PRODUCT STRUCTURE 197A

197A		
MODEL	NEXT ASSEMBLY	QTY.
USED ON		

DO NOT SCALE THIS DRAWING	DIMENSIONAL TOLERANCES UNLESS OTHERWISE SPECIFIED	DATE 6/26/90	SCALE 1:1	TITLE COMPONENT LAYOUT, DISPLAY BD.
KEITHLEY KEITHLEY INSTRUMENTS INC. CLEVELAND, OHIO 44139	XX=±.015 ANG.=±1°	DRN. MAH	ENG. APPR.	
	XXX=±.005 FRAC.=±1/64	MATERIAL	B	NO. 197A-110
	SURFACE MAX. 63	FINISH		





CONTACT DESCRIPTION

CONTACT	COM0	COM1	COM2
1	—	—	COM2
2	—	COM1	—
3	AUTO	REL	STO
4	dB	AC	RCL
5	BAT	▬	—
6	6f	6e	—
7	6a	6g	6d
8	6b	6c	—
9	5f	5e	5dp
10	5a	5g	5d
11	5b	5c	—
12	4f	4e	4dp
13	4a	4g	4d
14	4b	4c	—
15	3f	3e	3dp
16	3a	3g	3d
17	3b	3c	—
18	2f	2e	2dp
19	2a	2g	2d
20	2b	2c	—
21	1f	1e	1dp
22	1a	1g	1d
23	1b	1c	—
24	m	M	μ
25	V	k	m
26	C	Ω	A
27	—	—	RMT
28	COM0	—	—

KEITHLEY

KEITHLEY INSTRUMENTS INC.
CLEVELAND, OHIO 44139

TITLE

DISPLAY BOARD SCHEMATIC

SIZE	MODEL	NO	ECO	REV
C	197A	197A-116	900823	B

DRAWN	APPROVED	DATE
MAH	DCC	8/7/90

MODEL 1978 BATTERY PACK, PARTS LIST

Schematic Desig.	Description	Keithley Part No.
BT101	Battery Assembly, 12.0V Sealed Rechargeable Ni Cad	BA-40
C101	Capacitor, 250µF, 25V, Aluminum Electrolytic	C-314-250
C102	Capacitor, 10µF, 25V, Aluminum Electrolytic	C-314-10
CR101	Rectifier, Schottky Barrier, 1N5820	RF-53
P1009	Cable Assembly, 10 Conductor	CA-27-1
Q101	Transistor, NPN, High Voltage (TIP-49)	TG-137
R101	Resistor, 4.7Ω, 10%, 1W, Fixed, Fusible, Wound	R-334-4.7
R102	Resistor, 4.7Ω, 5%, 1/4W, Composition	R-76-4.7
R103	Resistor, 44.2kΩ, 1%, 1/8W, Metal Film	R-88-44.2k
R104	Resistor, 37.4kΩ, 1%, 1/8W, Metal Film	R-88-37.4k
R105	Resistor, 1.2M, 5%, 1/4W, Composition	R-76-1.2M
U101*	Voltage Converter, SI7661CJ	IC-340
U102	Voltage Comparator, LM393	IC-343
-	Heat Sink (used on U101)	HS-28
-	Standoff (Battery Board to Shield)	ST-137-6

*Static Sensitive Device

001-8761
ON

LTR	ECO NO.	REVISION	ENG.	DATE
A	9882	RELEASED	Mike	5-31-84
B	10402	R101 WAS R-1-4.7	MS	12-27-84
C	10967	CHG'D REV. FROM D TO F	[illegible]	2-20-86
D	12058	CHG'D ITEM 3 FROM C-314-250 TO C-314-220	[illegible]	4-3-87

ITEM	PART NO.	SCHEM. DESIG.	ZONE
1	1758-101	STAKING	D2
2			
⚠D 3	C-314-220	C101	D2
4	C-314-10	C102	D3
5			
6	CA-27-1	P1009	C1
7	IC-340	U101	D3
8	IC-343	U102	D3
9			
10			
11	CS-463	J1011	D3
12	CS-463	J1010	D2
13			
14	TG-137	Q101	D3
15			
16			
⚠ 17	R-334-4.7	R101	D2
18	R-76-4.7	R102	D2
19	R-88-442K	R103	D3
20	R-88-37.4K	R104	D3
21	R-76-1.2M	R105	D3
22			
23	RF-53	CR101	D3
24			
25	RT-10	RT101	D2
26			
27			
28	HS-28		D3
29			



1978		
MODEL	NEXT ASSEMBLY	QTY
USED ON		

DO NOT SCALE THIS DRAWING

KEITHLEY Keithley Instruments Inc. Cleveland, Ohio 44139

DIMENSIONAL TOLERANCES UNLESS OTHERWISE SPECIFIED
XX = ± .015 ANG. = ±1°
XXX = ± .005 FRAC = ±1/64
SURFACE MAX 63

DATE 5-31-84 SCALE 2-1
DRN [illegible] ENG. APPR. MA
MATERIAL
FINISH

TITLE COMPONENT LAYOUT BATTERY OPTION

SIZE B NO. 1978-100

BRUNING 44-131 58425 FORM 202778 REV D

901-8761 ON

ZONE	LTR	ECO NO	REVISION	ENG	DATE
	A	9882	RELEASED		5-31-84
	B	11072	ADDED REFERENCE TO 580.		12-16-84
	C	12058	CHGD C101 VALUE FROM 100 TO 220		4/3/87

MATES WITH J1009
OF MOTHER BOARD
(SEE 197-106 OR 580-106) ⚠3



NOTES:

1. ALL RESISTOR VALUES ARE IN OHMS UNLESS OTHERWISE MARKED (K-KILOHMS, M-MEGOHMS).
2. ALL CAPACITOR VALUES ARE IN MICROFARADS UNLESS OTHERWISE MARKED (pF-PICOFARADS)
3. ⚠3 DENOTES ANALOG COMMON.
4. —o— DENOTES TEST POINT.

HIGHEST SCHEMATIC DESIGNATIONS USED			
C102	Q101	BT101	R105
U102	RT101		

SCHEMATIC DESIGNATIONS NOT USED			

1978
MODEL | NEXT ASSEMBLY | QTY
USED ON

DO NOT SCALE THIS DRAWING
DIMENSIONAL TOLERANCES UNLESS OTHERWISE SPECIFIED
XX = ± .015 ANG = ± 1°
XXX = ± .005 FRAC = ± 1/64
SURFACE MAX 63
DATE 5-31-84 SCALE NONE
DRN JL ENG APPR MA
MATERIAL
FINISH
TITLE SCHEMATIC BATTERY OPTION
KEITHLEY Keithley Instruments Inc. Cleveland, Ohio 44139
C NO 1978-106

KEITHLEY

Service Form

Model No. _____ **Serial No.** _____ **Date** _____

Name and Telephone No. _____

Company _____

List all control settings, describe problem and check boxes that apply to problem. _____

_____

_____

- ❑ Intermittent
- ❑ Analog output follows display
- ❑ Particular range or function bad; specify _____
- ❑ IEEE failure
- ❑ Obvious problem on power-up
- ❑ Batteries and fuses are OK
- ❑ Front panel operational
- ❑ All ranges or functions are bad
- ❑ Checked all cables

Display or output (check one)

- ❑ Drifts
- ❑ Unstable
- ❑ Overload
- ❑ Unable to zero
- ❑ Will not read applied input

- ❑ Calibration only
- ❑ Data required
- ❑ Certificate of calibration required

(attach any additional sheets as necessary)

Show a block diagram of your measurement system including all instruments connected (whether power is turned on or not). Also, describe signal source.

Where is the measurement being performed? (factory, controlled laboratory, out-of-doors, etc.)

_____

_____

What power line voltage is used? _____ Ambient temperature? _____ °F

Relative humidity? _____ Other? _____

Any additional information. (If special modifications have been made by the user, please describe.)

_____

_____

Be sure to include your name and phone number on this service form.

KEITHLEY

Test Instrumentation Group
Keithley Instruments, Inc.
28775 Aurora Road
Cleveland, Ohio 44139

Printed in the U.S.A.